

**ARM<sup>®</sup> Cortex<sup>®</sup>-M0**  
**32-bit Microcontroller**

**NuMicro<sup>®</sup> Family**  
**NuTiny-SDK-NANO130**  
**User Manual**

*The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.*

*Nuvoton is providing this document only for reference purposes of NuMicro microcontroller based system design. Nuvoton assumes no responsibility for errors or omissions.*

*All data and specifications are subject to change without notice.*

For additional information or questions, please contact: Nuvoton Technology Corporation.

[www.nuvoton.com](http://www.nuvoton.com)

**Table of Contents**

1 OVERVIEW ..... 3

2 NUTINY-SDK-NANO130 INTRODUCTION..... 4

    2.1 NuTiny -SDK-NANO130 Jumper Description ..... 5

        2.1.1 Power Setting ..... 5

        2.1.2 Debug Connector ..... 5

        2.1.3 USB Connector ..... 5

        2.1.4 Extended Connector ..... 5

        2.1.5 Button ..... 5

        2.1.6 Power Connector ..... 5

    2.2 Pin Assignment for Extended Connector ..... 6

    2.3 NuTiny-SDK-NANO130 PCB Placement ..... 9

3 How to Start NuTiny-SDK-NANO130 on the Keil  $\mu$ Vision<sup>®</sup> IDE ..... 10

    3.1 Keil uVision<sup>®</sup> IDE Software Download and Install ..... 10

    3.2 Nuvoton Nu-Link Driver Download and Install ..... 10

    3.3 Hardware Setup ..... 10

    3.4 Example Program ..... 11

4 How to Start NuTiny-SDK-NANO130 on the IAR Embedded Workbench ..... 12

    4.1 IAR Embedded Workbench Software Download and Install ..... 12

    4.2 Nuvoton Nu-Link Driver Download and Install ..... 12

    4.3 Hardware Setup ..... 12

    4.4 Example Program ..... 13

5 NuTiny-SDK-NANO130 Schematic ..... 14

    5.1 NuTiny-EVB-NANO130 Schematic ..... 14

    5.2 GPIO for 128 pin Schematic ..... 15

    5.3 Nu-Link-Me Schematic ..... 16

    5.4 4x42 TN LCD Schematic ..... 17

6 REVISION HISTORY ..... 18

# 1 OVERVIEW

NuTiny-SDK-NANO130 is the specific development tool for NuMicro® NANO130 series. Users can use NuTiny-SDK-NANO130 to develop and verify the application program easily.

NuTiny-SDK-NANO130 includes two portions. One is NuTiny-EVB-NANO130 and the other is Nu-Link-Me. NuTiny-EVB-NANO130 is the evaluation board and Nu-Link-Me is its Debug Adaptor. Thus, users do not need other additional ICE or debug equipments.

NuTiny-SDK-NANO130\_TNLCD includes one 4x42 LCD panel for NuTiny-EVB-NANO130. Users can connect NuTiny-SDK-NANO130\_TNLCD to NuTiny-EVB-NANO130 to develop and verify the application.




Figure 1-1 NuTiny-SDK-NANO130 with NuTiny-SDK-NANO130\_TNLCD

## 2 NUTINY-SDK-NANO130 INTRODUCTION

NuTiny-SDK-NANO130 uses the NANO130KE3BN as the target microcontroller. Figure 2-1 is NuTiny-SDK-NANO130 for NANO130 series, the left portion is called NuTiny-EVB-NANO130 and the right portion is Debug Adaptor called Nu-Link-Me. Figure 2-2 is NuTiny-SDK-NANO130\_TNLCD for NuTiny-SDK-NANO130 LCD display applications.

NuTiny-EVB-NANO130 is similar to other development boards. Users can use it to develop and verify applications to emulate the real behavior. The on board chip covers NANO130 series features. The NuTiny-EVB-NANO130 can be a real system controller to design users' target systems.

The Nu-Link-Me is a Debug Adaptor. The Nu-Link-Me Debug Adaptor connects your PC's USB port to your target system (via Serial Wired Debug Port) and allows you to program and debug embedded programs on the target hardware. To use Nu-Link-Me Debug adaptor with IAR or Keil, please refer to "Nuvoton NuMicro® IAR ICE driver user manual" or "Nuvoton NuMicro® Keil ICE driver user manual" in detail. These two documents will be stored in the local hard disk when the user installs each driver.




Figure 2-1 NuTiny-SDK-NANO130 (PCB Board)




Figure 2-2 NuTiny-SDK-NANO130\_TNLCD (PCB Board)

## 2.1 NuTiny -SDK-NANO130 Jumper Description

### 2.1.1 Power Setting

- JP2:  $V_{DD33}$  Voltage connector in NuTiny-EVB-NANO130
- ICE J2: USB port in Nu-Link-Me
- J1: USB port in NuTiny-EVB-NANO130

Model	JP2 $V_{DD33}$	ICE J2 ICE USB Port	J1 USB Port	MCU Voltage
Model 1	DC 3.3V Output	Connect to PC	X	DC 3.3V
Model 2	DC 3.3V Output	X	Connect to PC	DC 3.3V
Model 3	DC 1.8V ~ 3.6V Input	X	X	Voltage by JP2 Input

X: Unused.

### 2.1.2 Debug Connector

- JP4: Connector in target board (NuTiny-EVB-NANO130) for connecting with Nuvoton ICE adaptor (Nu-Link-Me)
- ICE JP8: Connector in ICE adaptor (Nu-Link-Me) for connecting with a target board (NuTiny-EVB-NANO130)

### 2.1.3 USB Connector

- J1: Micro USB Connector in NuTiny-EVB-NANO130 connected to a PC USB port
- ICE J2: Micro USB Connector in Nu-Link-Me connected to a PC USB port

### 2.1.4 Extended Connector

- JP11, JP15, JP16, and JP17: Show all chip pins in NuTiny-EVB-NANO130
- JP1, JP5, JP6, JP7: Show all chip pins in NuTiny-EVB-NANO130, and connected to NuTiny-SDK-NANO130\_TNLCDC

### 2.1.5 Button

- SW1: Reset button in NuTiny-EVB-NANO130
- SW2: PC.12 button in NuTiny-EVB-NANO130

### 2.1.6 Power Connector

- JP2:  $V_{DD}$  connector in NuTiny-EVB-NANO130
- JP3: GND connector in NuTiny-EVB-NANO130

## 2.2 Pin Assignment for Extended Connector

NuTiny-EVB-NANO130 provides NANO130KE3BN on board and the extended connector for LQFP128-pin. Table 2-1 is the pin assignment for NANO130KE3BN.

Pin No	Pin Name	Pin No	Pin Name
01	PE.13	65	PE.4/SPI0_MOSI0
02	PB.14/INT0/SC2_CD/SPI2_SS1	66	PE.3/SPI0_MISO0
03	PB.13/EBI_AD1	67	PE.2/SPI0_CLK
04	PB.12/EBI_AD0/FCLKO	68	PE.1/PWM1_CH3/SPI0_SS0
05	NC	69	PE.0/PWM1_CH2/I2S_MCLK
06	X32_OUT	70	PC.13/SPI1_MOSI1/PWM1_CH1/SNOO PER/INT1/I2C0_SCL
07	X32_IN	71	PC.12/SPI1_MISO1/PWM1_CH0/INT0/I 2C0_SDA
08	NC	72	PC.11/SPI1_MOSI0/UART1_TXD
09	PA.11/I2C1_SCL/EBI_nRD/SC0_RST/S PI2_MOSI0	73	PC.10/SPI1_MISO0/UART1_RXD
10	PA.10/I2C1_SDA/EBI_nWR/SC0_PWR/ SPI2_MISO0	74	PC.9/SPI1_CLK/I2C1_SCL
11	PA.9/I2C0_SCL/SC0_DAT/SPI2_CLK	75	PC.8/SPI1_SS0/EBI_MCLK/I2C1_SDA
12	PA.8/I2C0_SDA/SC0_CLK/SPI2_SS0	76	PA.15/PWM0_CH3/I2S_MCLK/TC3/SC0 _PWR/UART0_TXD
13	PD.8	77	PA.14/PWM0_CH2/EBI_AD15/TC2/UAR T0_RXD
14	PD.9	78	PA.13/PWM0_CH1/EBI_AD14/TC1/I2C0 _SCL
15	PD.10	79	PA.12/PWM0_CH0/EBI_AD13/TC0/I2C0 _SDA
16	PD.11	80	PF.0/INT0/ICE_DAT
17	PD.12	81	PF.1/FCLKO/INT1/ICE_CLK
18	PD.13	82	NC
19	PB.4/UART1_RXD/SC0_CD/SPI2_SS0	83	VDD
20	PB.5/UART1_TXD/SC0_RST/SPI2_CLK	84	NC
21	PB.6/UART1_RTSn/EBI_ALE/SPI2_MIS OO	85	VSS
22	PB.7/UART1_CTSn/EBI_nCS/SPI2_MO SIO	86	VSS
23	NC	87	AVSS

24	LDO_CAP	88	AVSS
25	NC	89	PA.0/AD0/SC2_CD
26	NC	90	PA.1/AD1/EBI_AD12
27	VDD	91	PA.2/AD2/EBI_AD11/UART1_RXD
28	NC	92	PA.3/AD3/EBI_AD10/UART1_TXD
29	VSS	93	PA.4/AD4/EBI_AD9/SC2_PWR/I2C0_S DA
30	VSS	94	PA.5/AD5/EBI_AD8/SC2_RST/I2C0_SC L
31	VSS	95	PA.6/AD6/EBI_AD7/TC3/SC2_CLK/PW M0_CH3
32	VSS	96	PA.7/AD7/EBI_AD6/TC2/SC2_DAT/PW M0_CH2
33	PE.12	97	VREF
34	PE.11	98	NC
35	PE.10	99	AVDD
36	PE.9	100	PD.0/UART1_RXD/SPI2_SS0/SC1_CLK /AD8
37	PE.8	101	PD.1/UART1_TXD/SPI2_CLK/SC1_DAT /AD9
38	PE.7	102	PD.2/UART1_RTSn/I2S_LRCLK/SPI2_ MISO0/SC1_PWR/AD10
39	NC	103	PD.3/UART1_CTSn/I2S_BCLK/SPI2_M OSI0/SC1_RST/AD11
40	NC	104	NC
41	NC	105	PD.4/I2S_DI/SPI2_MISO1/SC1_CD
42	NC	106	PD.5/I2S_DO/SPI2_MOSI1
43	NC	107	PC.7/DA1_OUT/EBI_AD5/TC1/PWM0_ CH1
44	PB.0/UART0_RXD/SPI1_MOSI0	108	PC.6/DA0_OUT/EBI_AD4/TC0/SC1_CD/ PWM0_CH0
45	PB.1/UART0_TXD/SPI1_MISO0	109	PC.15/EBI_AD3/TC0/PWM1_CH2
46	PB.2/UART0_RTSn/EBI_nWRL/SPI1_C LK	110	PC.14/EBI_AD2/PWM1_CH3
47	PB.3/UART0_CTSn/EBI_nWRH/SPI1_S S0	111	PB.15/INT1/SNOOPER/SC1_CD
48	PD.6	112	NC



49	PD.7	113	XT1_IN
50	PD.14	114	XT1_OUT
51	PD.15	115	NC
52	PC.5/SPI0_MOSI1	116	nRESET
53	PC.4/SPI0_MISO1	117	VSS
54	PC.3/SPI0_MOSI0/I2S_DO/SC1_RST	118	VSS
55	PC.2/SPI0_MISO0/I2S_DI/SC1_PWR	119	NC
56	PC.1/SPI0_CLK/I2S_BCLK/SC1_DAT	120	VDD
57	PC.0/SPI0_SS0/I2S_LRCLK/SC1_CLK	121	NC
58	PE.6	122	PF.4/I2C0_SDA
59	NC	123	PF.5/I2C0_SCL
60	NC	124	VSS
61	PE.5/PWM1_CH1	125	PVSS
62	PB.11/PWM1_CH0/TM3/SC2_DAT/SPI0_MISO0	126	PB.8/STADC/TM0/INT0/SC2_PWR
63	PB.10/SPI0_SS1/TM2/SC2_CLK/SPI0_MOSI0	127	PE.15
64	PB.9/SPI1_SS1/TM1/SC2_RST/INT0	128	PE.14

Table 2-1 Pin Assignment for NANO130



### 2.3 NuTiny-SDK-NANO130 PCB Placement

Users can refer to Figure 2-2 for the NuTiny-SDK-NANO130 PCB placement and Figure 2-4 for the NuTiny-SDK-NANO130\_TNLCDC PCB placement.




Figure 2-3 NuTiny-SDK-NANO130 PCB Placement




Figure 2-4 NuTiny-SDK-NANO130\_TNLCDC PCB Placement

### 3 HOW TO START NUTINY-SDK-NANO130 ON THE KEIL MVISION® IDE

#### 3.1 Keil uVision® IDE Software Download and Install

Please visit the Keil company website (<http://www.keil.com>) to download the Keil  $\mu$ Vision® IDE and install the RVMDK.

#### 3.2 Nuvoton Nu-Link Driver Download and Install

Please visit the Nuvoton company NuMicro® website (<http://www.nuvoton.com/NuMicro>) to download “NuMicro® Keil  $\mu$ Vision® IDE driver” file. When the Nu-Link driver has been well downloaded, please unzip the file and execute the “Nu-Link\_Keil\_Driver.exe” to install the driver.

#### 3.3 Hardware Setup

The hardware setup is shown as Figure 3-1.



Figure 3-1 Hardware Setup

### 3.4 Example Program

This example demonstrates the ease of downloading and debugging an application on a NuTiny-SDK-NANO130 board. It can be found on Figure 3-2 list directory and downloaded from Nuvoton NuMicro® website.












Figure 3-2 Example Directory

To use this example:

Connects the NuTiny-SDK-NANO130\_TNLCD to NuTiny-SDK-NANO130. The LCD panel will display a NUVOTON logo.

-  **Start µVision®**
- **Project-Open**  
Open the SYS.uvproj project file
-  **Project - Build**  
Compile and link the SYS application
-  **Flash – Download**  
Program the application code into on-chip Flash ROM
-  **Start debug mode**  
Using the debugger commands, you may:
  - ◆  Review variables in the watch window
  - ◆  Single step through code
  - ◆  RST Reset the device
  - ◆  Run the application

## 4 HOW TO START NUTINY-SDK-NANO130 ON THE IAR EMBEDDED WORKBENCH

### 4.1 IAR Embedded Workbench Software Download and Install

Please connect to IAR company website (<http://www.iar.com>) to download the IAR Embedded Workbench and install the EWARM.

### 4.2 Nuvoton Nu-Link Driver Download and Install

Please visit the Nuvoton company NuMicro<sup>®</sup> website (<http://www.nuvoton.com/NuMicro>) to download the “NuMicro<sup>®</sup> IAR EWARM Driver” file. When the Nu-Link driver has been well downloaded, please unzip the file and execute the “Nu-Link\_Keil\_Driver.exe” to install the driver.

### 4.3 Hardware Setup

The hardware setup is shown as Figure 4-1.




Figure 4-1 Hardware Setup

### 4.4 Example Program

This example demonstrates the ease of downloading and debugging an application on a NuTiny-SDK-NANO130 board. It can be found on Figure 4-2 list directory and downloaded from Nuvoton NuMicro® website.










Figure 4-2 Example Directory


To use this example:

Connects the NuTiny-SDK-NANO130\_TNLCD to NuTiny-SDK-NANO130. The LCD panel will display a NUVOTON logo.

-  Start IAR Embedded Workbench
-  Project – Download and Debug  
Program the application code into on-chip Flash ROM
- File-Open-Workspace  
Open the SYS.eww workspace file
-  Single step through code
-  Reset the device
-  Run the application
-  Project - Make  
Compile and link the SYS application


### 5 NUTINY-SDK-NANO130 SCHEMATIC

#### 5.1 NuTiny-EVB-NANO130 Schematic



<b>nuvoTon</b>		
NuTiny-EVB-Nano130-LQFP128 V1.2		
Classm	NANO130KE3BN SCH	V1.2
Friday, December 06, 2013	1	2 3

### 5.2 GPIO for 128 pin Schematic



**nuvoTon**


NuTiny-EVB-Nano130-LQFP128 V1.2

Column	OTHER.SCH	V1.1
File	05emul_05_2013	3 3

NUTINY-SDK-NANO130 USER MANUAL




5.3 Nu-Link-Me Schematic



NUTINY-SDK-NANO130 USER MANUAL

### 5.4 NuTiny-SDK-NANO130\_TNLCDC Schematic



**nuvoTon**

NuTiny-EV8-TNLCDC-Nano130-LQFP128 V1.0

Custom	4X42 TN LCD glass.SCH	V1.0
Thursday, July 12, 2012		1 1

## 6 REVISION HISTORY

Date	Revision	Description
2012.10.16	1.00	1. Initially issued.
2013.01.08	1.01	1. Change the value of C7 and C8 in the schematics from 10 pF to 6 pF.
2018.02.26	1.02	<ol style="list-style-type: none"> <li>1. Updated the figure of NuTiny-SDK-NANO130 PCB Board in chapter 1.</li> <li>2. Updated th descriptions in chapter 2.</li> <li>3. Updated the example program descriptions in chapter 3 and 4.</li> <li>4. Updated NuTiny-SDK-NANO130 schematics in chapter 5.</li> </ol>

### Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

---

*Please note that all data and specifications are subject to change without notice.  
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*