

# PowIRCenter Installation and User Guide

## About this document

### Scope and purpose

The purpose of this document is to provide a comprehensive and easy to follow guide of the PowIRCenter software. The scope applies to all the aspects of the software from Installation to troubleshooting.

### Intended audience

DC/DC power supply designers using the PowIRCenter software to program International Rectifier digital IC's

## Table of Contents

<b>1</b>	<b>PowIRCenter Features</b> .....	<b>3</b>
<b>2</b>	<b>System Requirements</b> .....	<b>4</b>
<b>3</b>	<b>Download IR PowIRCenter</b> .....	<b>5</b>
3.1.	POL PowIRCenter (no license).....	5
3.2.	Full PowIRCenter (license required).....	5
<b>4</b>	<b>Install IR PowIRCenter</b> .....	<b>7</b>
<b>5</b>	<b>UnInstall IR PowIRCenter</b> .....	<b>11</b>
<b>6</b>	<b>Hardware Setup</b> .....	<b>12</b>
6.1	Firmware Update.....	12
<b>7</b>	<b>Getting Started</b> .....	<b>13</b>
7.1	Automatic Updates for "Full" PowIRCenter .....	13
7.2	Launching the GUI - for POL devices only.....	14
7.3	Launching the GUI - for POL and Multi-Phase Devices .....	14
<b>8</b>	<b>Main Screen Interface</b> .....	<b>15</b>
<b>9</b>	<b>Device Manager</b> .....	<b>16</b>
9.1	Tree View Structure.....	16
9.2	Dot Colors .....	16
9.3	Add/Delete Devices .....	17
9.4	Move Device Up/Down .....	17
9.5	Editing Tree View Text and I2C/PMBus Address .....	17
9.6	Expand/Collapse Device Manager Tree View .....	18
<b>10</b>	<b>New/Open/Save Board Designs</b> .....	<b>19</b>
<b>11</b>	<b>System Status</b> .....	<b>20</b>
<b>12</b>	<b>Clear Faults</b> .....	<b>21</b>
<b>13</b>	<b>Auto Populate Devices</b> .....	<b>22</b>
<b>14</b>	<b>Read Registers from Devices</b> .....	<b>23</b>
<b>15</b>	<b>Device Level - Register Map (in "Full" PowIRCenter only)</b> .....	<b>24</b>
<b>16</b>	<b>Device Level – Design Tools</b> .....	<b>25</b>
<b>17</b>	<b>Device Level – Utilities</b> .....	<b>26</b>


<b>18</b>	<b>Loop Level - PMBus interface .....</b>	<b>27</b>
18.1	Command and Summary.....	27
18.2	PMBus Status .....	28
18.3	Display Basic PMBus Commands (only for Acadia, Manhattan, and Rocky).....	29
<b>19</b>	<b>Floating Status Window.....</b>	<b>30</b>
<b>20</b>	<b>Group Vout Control .....</b>	<b>31</b>
<b>21</b>	<b>Group Sequencing Control .....</b>	<b>32</b>
<b>22</b>	<b>Multi-Device Programmer .....</b>	<b>33</b>
22.1	Important Note .....	33
22.2	User Interface .....	33
22.3	Programming Procedure .....	34
22.4	Verify Only .....	34
<b>23</b>	<b>I2C/PMBus Utility .....</b>	<b>35</b>
<b>24</b>	<b>Linear Calculator Utility .....</b>	<b>36</b>
<b>25</b>	<b>File Format .....</b>	<b>38</b>
25.1	Configuration File .....	38
25.2	Board Design File .....	39
<b>26</b>	<b>Troubleshooting.....</b>	<b>40</b>
26.1	Error Message: "The application failed to initialize properly (0xc0000135)."	40
26.2	Error Message: "(.NET) Unable to find a version of the runtime to run this application."	40
26.3	Issue: Cannot Update GUI.....	41
26.4	Issue: Cannot Communicate with the Chip (I2C / PMBus) .....	42
26.5	Issue: Text is misaligned or "floats" .....	47
26.6	Issue: PowIRCenter is extremely slow with the dongle plugged in. ....	49
26.7	Issue: GUI cannot detect devices on the bus, or Autopopulate feature does not work .....	49
26.8	Issue: Unable to download updates due to proxy servers requirement .....	50

## 1 PowIRCenter Features

- Control and monitor up to 20 devices.
- Supports Acadia, Baxter, Comanche, Lucas, Katahdin, Manhattan, Rocky, and Salem family devices.
- Automatic dongle firmware update.
- Dedicated screens for
  - PMBus commands and summary
  - System status : Vin, Iin, Vout, Iout, Vcc, Temperature
  - Register Map
  - Group Vout Control: Margin High, Margin Low, and On/Off
  - Sequencing : On/Off delay, rise time, fall time
  - Multiple-device programmer
  - Design Wizards

## 2 System Requirements

- Ensure that you are connected to the internet.
- *Microsoft .NET Framework 4.0* must be installed. This can be downloaded [here](#) (if the link does not work, paste "<http://www.microsoft.com/en-us/download/details.aspx?id=17718>" without the quotes into your internet browser). After Click on **Download**, the following window shows,



Please **uncheck** all the recommends, and click on **No thanks and continue**.

- You can check which version of .NET you have by following the instructions [here](#) (if the link does not work, paste "<http://support.microsoft.com/kb/318785>" without the quotes into your internet browser).
- Windows 7 or 8
  - If you're using *Windows 7 or 8*, you may be prompted with a security warning whenever you run a program. For this setup, allow these programs to run.
- USB2.0 port (not compatible with USB3.0)

## 3 Download IR PowIRCenter

There are 2 versions of the GUI. The majority of users should only download and use the "POL" version which does not require a license. For some advanced applications and products, your IR/Infineon representative will provide a license file in which case the user should download the "Full" version.

	POL PowIRCenter	Full PowIRCenter
<b>Software location</b>	<a href="http://www.infineon.com">www.infineon.com</a>	FTP site
<b>Easy self-install</b>	Yes	No
<b>License file required</b>	No	Yes
<b>Auto-update capability</b>	No	Yes
<b>Advanced &amp; non-released products</b>	No	Yes

### 3.1. POL PowIRCenter (no license)

Designed for ease of use, this single file download is self-extracting and self-installing and contains all necessary files and drivers (USBXpress & SiLabs). Download from:

<http://www.infineon.com/cms/en/product/promopages/power-center-software/>


After installation, proceed to the "Hardware Setup" section on page 9 of this guide.

### 3.2. Full PowIRCenter (license required)

**Caution:** only download this version if you have been provided with a license for access to advanced and non-released products.

1. Create a folder in C drive as C:\IR\_PowIRCenter
2. Copy and paste "ftp://irdpdc\_ro:mem2011@sftp.irf.com/" (Without the quotes) to Windows Explorer.

Some users may see a dialog box asking for Authentication.




If you see this prompt, type in the following credentials:


User Name: irdpdc\_ro

Password: mem2011

3. Click the folder labeled IR PowIRCenter in the FTP server.




4. Right click on IR PowIRCenter Installation Package.exe and select Copy to Folder... When the dialog box pops up, navigate to Desktop. Click Ok.




## 4 Install IR PowIRCenter


1. **Administrator Access / Administrator Privilege:** If you are not logged into an Administrator account or your IT policy requires you to request Administrator privilege, you must gain Administrator privilege before continuing the installation process. This process is specific to your company. Contact your IT representative if you are unsure how to gain Administrator privilege.
2. Go to **Desktop**, right-click the file **IR PowIRCenter Installation Package.exe**, and select **Run as administrator**.



- a. You may also receive a prompt asking you to input your credentials and/or to allow the program to run. Input your credentials if necessary and click **Yes**.




3. Click **Install** when prompted to do so. This will extract the GUI files to **C:\IR\_PowIRCenter**.






4. The Installation File will launch the USBXpress Driver v4.0 Install. Click Next.



5. Once the driver has finished installing, click **Finish**




## 5 Uninstall IR PowIRCenter

Please note the IR PowIRCenter is not deployed through setup.exe. Therefore, there is no need to add/remove the IR PowIRCenter GUI from **Control Panel -> Add Remove Program**. Just delete the **C:\IR\_PowIRCenter** folder or files if the user doesn't want to keep them.

## 6 Hardware Setup


The typical setups are shown below. The USB005 dongle has two layers of firmware, the resident bootloader layer which will not be modified is responsible for updating and flashing the application firmware. The GUI will prompt the user to update the application firmware if the GUI detects the current version is out-of-date.

**CAUTION:** the dongle firmware for the PowIRCenter GUI is not backward-compatible with older GUIs such as IR DPDC GUI.




### 6.1 Firmware Update

The GUI will prompt the user to update the firmware if there is a newer firmware available. The user has the option not to update, but updating is recommended.



Click **Exit** after the update.




## 7 Getting Started

There are three ways to launch the “Full” PowIRCenter GUI.


- **IR PowIRCenter Update.exe** – check and download updates if there are newer files in the server.
- **IR PowIRCenter.exe** – Launch the GUI directly without checking for updates.
- **IR PowIRCenter** – Shortcut located on your Desktop.

### 7.1 Automatic Updates for “Full” PowIRCenter


1. Make sure your computer is connected to the Internet, then launch the GUI by double-clicking **C:\IR\_PowIRCenter\IR PowIRCenter Update.exe** or the shortcut named **IR PowIRCenter** located on your desktop.



2. If there are any updates available from the IR Server, this screen will appear. Click **Update Now** to start downloading or click **Skip Updates** to download later.



3. After download is complete, click the **Exit** button and restart IR PowIRCenter.



Please note if there are no updates, the IR PowIRCenter GUI will start immediately after checking.

## 7.2 Launching the GUI - for POL devices only

POL devices and related information are generally available on the Infineon website.


1. Double-click **IR PowIRCenter.exe** from **C:\IR\_PowIRCenter** or the shortcut named **IR PowIRCenter** located on your desktop.
2. If there is no **IR DPDC License.txt** license file in the **C:\IR\_PowIRCenter** folder. The GUI will run in POL mode. Only the following devices are available for use.
  - Manhattan Family : IR38060, IR38061, IR36062, IR38063, IR38064
  - Comanche Family : IR36021
  - Rocky Family : IRPS5401

## 7.3 Launching the GUI - for POL and Multi-Phase Devices

Multi-phase devices, due to their proprietary technology, are generally restricted and require authorization from Infineon to access information and use the devices.

1. Ask an IFX/IR FAE for **IR DPDC License.txt** file. Copy and paste the file to **C:\IR\_PowIRCenter** folder.
2. Double-click **IR PowIRCenter.exe** from **C:\IR\_PowIRCenter** or the shortcut named **IR PowIRCenter** located on your desktop.
3. All IR digital controller devices in Acadia, Baxter, Comanche, Lucas, Katahdin, Manhattan, Rocky, and Salem will be available for usage.

## 8 Main Screen Interface




1. Menu
2. Board level commands and utilities
3. Device manager
4. Common area for system status, register map, PMBus command and summary
5. USB connection status.
6. Dongle hardware part number
7. Dongle firmware version
8. I2C/PMBus speed
9. License expiration days left
10. PMBus Online/Offline Mode
  - a. Only adjustable in when using PMBus in Acadia, Manhattan, and Rocky.
11. GUI status and message

## 9 Device Manager

### 9.1 Tree View Structure

Device manager is a three level tree view structure - board level, device level, and loop level. The board level is the root or board design, it cannot be deleted. When you add a new device, it will be attached under the board. Depending on the number of loops and PMBus capability, the loop level will be automatically created under the device. In the example below, selecting Manhattan IR38063 adds 1 loop and Rocky IRPS5401 adds 5 loops.



### 9.2 Dot Colors

The colored dot in the device manager has different meaning.

Board Level:

- System faults or alarms
- No faults or alarms

Device Level:

- i2c bus good
- Device ID mismatch
- No i2c device detected at the address

Loop Level:


- PMBus good
- Device ID mismatch
- No PMBus device detected at the address



## 9.3 Add/Delete Devices

To add a device, right-click the **Device Manager** and select a device under **Add Device**.

To delete a device, right-click the device in the **Device Manager** and select **Delete Device**.




## 9.4 Move Device Up/Down

1. Click the device to be reordered
2. Right click on **Device Manager** then click **Move Device Up** or **Move Device Down**

## 9.5 Editing Tree View Text and I2C/PMBus Address

1. Click the device or loop to be edited
2. Right click on **Device Manager** then click **Edit Text/Address**





## 9.6 Expand/Collapse Device Manager Tree View

A button in the Menu Bar controls this function:



Click it once to collapse the Device Tree.  
Click it again to expand the Device Tree.



## 10 New/Open/Save Board Designs

A Board Design File contains all the information for a board design, such as the number of devices, the family of each device, its load model and its configuration file information. The GUI requires this information to accurately model the device's behavior.



Click this icon to start a new board design. This will clear all devices from the Device Tree.




Click this icon to open an existing board design from a file.



Click this icon to save the current board design to a file.


## 11 System Status

Clicking the board level in the device manager will show all devices vital data in a series of “status meters”. Here is an explanation of a status meter’s display: All data displayed here is read from the controller.



1. Device title text copied from the tree view
2. Loop title text copied from the tree view – Green = Normal; Orange = PMBus Alert; Red = Fault
3. Vin – input voltage
4. Iin – input current (where applicable. Not all devices measure Iin.)
5. Vcc – IC bias supply (typically 3.3V)
6. Vout
7. Iout total current
8. Temperature
9. Loop Power on/off indicator – Green = loop on; Grey = loop off

If the loop has faults, move the mouse cursor to the loop title area to make the fault details appear.



**12**

## Clear Faults



Clicking the clear faults icon will clear all alarms or fault registers if the faults conditions are corrected.

**13**

## **Auto Populate Devices**



This utility scans the PMBus and populates the GUI with all devices found.


## 14 Read Registers from Devices



This utility reads all registers of all devices and updates the GUI. The user should perform the read registers operation after adding devices or auto populating devices.

## 15 Device Level - Register Map (in "Full" PowIRCenter only)

Click a device in the device manager to bring up the register map of the device. You can load/save the configuration file or read/write registers.













1. Register Map tab
2. Design Tools tab – Contains tools to configure control registers
3. Utilities tab – Contains tools to assist system or board design
4. Tree view. Click to select a register. 5 – 9 are associated with tree view.
  5. Tree view register description
  6. Tree view register value (for reading or writing)
  7. Tree view register value decoded.
  8. Read the tree view register
  9. Write the tree view register
10. Map view. Click to select a register. 11 – 14 are associated with map view.
  11. Map view register address
  12. Map view register data
  13. Write the map view register
  14. Read the map view register
15. Read all registers and update register map in area 10
16. Write all registers in area 10 to the device
17. Load a configuration file
18. Save user and manufacture section to a configuration file
19. Load a standard (preset) configuration file from the provided list.
20. Register Map Status











## 16 Device Level – Design Tools

Register Map   Design Tools   Utilities

<div style="margin-bottom: 10px;">  <p><b>1. Device Operating Mode</b> Part Number, Intel, AMD, MPOL, nVidia PWM, GPU</p> </div> <div style="margin-bottom: 10px;">  <p><b>2. System Settings</b> Loop, I2C/PMBus Address, Vin, TSense, Fsw</p> </div> <div style="margin-bottom: 10px;">  <p><b>3. Loadline &amp; Current Sensing</b> Current Sensing and Loadline NTC</p> </div> <div style="margin-bottom: 10px;">  <p><b>4. Load Model &amp; Loop Stability</b> Crossover Frequency, Gain Margin, Phase Margin, Output Impedance</p> </div> <div style="margin-bottom: 10px;">  <p><b>5. Faults &amp; Protection</b> Level and Behavior of OTP, OCP, OVP, UVP and UVLO</p> </div>	<div style="margin-bottom: 10px;">  <p><b>6. Dynamic VID</b> DVID Slew Rate</p> </div> <div style="margin-bottom: 10px;">  <p><b>7. Power Saving</b> Power Saving Mode, Diode Emulation, Current Threshold</p> </div> <div style="margin-bottom: 10px;">  <p><b>8. Transient Settings</b> AC Load, Adaptive Transient Algorithm</p> </div> <div style="margin-bottom: 10px;">  <p><b>9. Offset Adjust</b> Current, Voltage and Temperature Offset Control</p> </div> <div style="margin-bottom: 10px;">  <p><b>10. Security</b> Register Read/Write Protection</p> </div>
---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## 17 Device Level – Utilities


Register Map | Design Tools | Utilities

 <b>Baxter Device Programmer</b> Program register data to OTP	 <b>Ripple Estimator</b> VIN and lin
 <b>Data Logger</b> Telemetry data	 <b>Configuration Comparator</b> Configuration file or register data
 <b>TOB Calculator</b> Loadline and Current Measurement	 <b>Register Map Decoder</b> Register data and information
 <b>Thermal NTC Voltage</b> NTC and IR3555 TOUT	 <b>Device Status</b> Phase current and telemetry
 <b>Configuration Checker</b> Auto correct of configuration data	

## 18 Loop Level - PMBus interface

Clicking a loop in the device manager will bring up the PMBus interface of the loop. You can read/write individual PMBus command and monitor all PMBus command values.

### 18.1 Command and Summary




1. Select a PMBus command to read or write from the drop-down list.
2. Sort the PMBus command list by Command Code. Click again to sort by Command Name. Default is sort by Command Name.
3. Set a new value of the command – this area changes based upon the selected command
4. Description of the command
5. Read the selected PMBus command
6. Write the selected PMBus command with a new value
7. Toggle to enable or disable Continuous PMBus Command Updates. If enabled, PMBus values will update every second.
8. Update PMBus Command once. If Continuous PMBus Command Updates is enabled, this button is disabled.
9. PMBus commands summary. *Clicking any entry in the summary table will change the command in the drop-down list.*

## 18.2 PMBus Status


PMBus status is updated every second.

- Red – alarm or fault
- Black - normal
- Gray – not supported



## 18.3 Display Basic PMBus Commands (only for Acadia, Manhattan, and Rocky)

These 3 devices have an option to filter the command list down to a few basic controls. This is selected by ticking the “Basic Commands” option at the bottom of the PMBus Page. To view the full list of PMBus commands, tick the “All Commands” option.



The screenshot shows the PowIRCenter interface for configuring PMBus commands. On the left, the 'FREQUENCY\_SWITCH' command (code 33) is selected, showing a value of 225 KHz. Below the value is a 'Linear Format Exponent' section with radio buttons for 0 and 1. A detailed description of the command is provided in a scrollable text area. At the bottom, there are 'Read' and 'Write' buttons. On the right, a table lists various PMBus commands and their current values. At the bottom right, there are radio buttons for 'Basic Commands' (selected) and 'All Commands', along with 'Stop Updating' and 'Read Once' buttons.


Code	Command	Value
01	OPERATION	Immediate Off
02	ON_OFF_CONFIG	0x00
21	VOUT_COMMAND	0.000 V
24	VOUT_MAX	0.000 V
27	VOUT_TRANSITION_RATE	0 mV/us
29	VOUT_SCALE_LOOP	0.000
33	FREQUENCY_SWITCH	0 KHz
35	VIN_ON	0.000 V
36	VIN_OFF	0.000 V
40	VOUT_OV_FAULT_LIMIT	NaN V
46	IOUT_OC_FAULT_LIMIT	0.000 A

## 19 Floating Status Window

When a device or loop is selected, a floating status meter will appear to show all vital data of the device. The floating status meter can be placed anywhere on the screen so the status can be monitored as device changes or PMBus commands are sent. Click button 10 to minimize the floating meter to the lower left corner:

Floating Meter

Double clicking will bring it back:



1. Device title text (set in the tree view)
2. Loop title text (set in the tree view)
  - Green = Normal;
  - Orange = Fault related to PMBus;
  - Red = Fault related to Fail code
3. Vin – input voltage
4. Iin – input current (where applicable. Not all devices measure Iin.)
5. Vcc – device bias voltage e.g. 3.3V
6. Vout
7. Iout total current
8. Temperature
9. Loop on/off indicator – Green = loop on; Black = loop off
10. Minimize the status meter

## 20 Group Vout Control



This interface facilitates using the PMBus GROUP command to turn on/off all devices at the same time.

Device	Loop	Vout (V)	Margin High (V)	Margin Low (V)
IR3581	Loop 1	0.000	0.000	0.000
IR3581	Loop 2 n/a	0.000	0.000	0.000
IR3581	Loop 1	0.000	0.000	0.000
IR3581	Loop 2 n/a	0.000	0.000	0.000
IR38063	VTT	1.000	1.059	0.984
IR38063	VPP	2.500	2.621	2.375
IR38063	3V3	3.305	3.453	3.133
IR38063	5V0	5.000	5.250	4.754

The graph shows Vout (V) on the y-axis (0 to 6) and Time (ms) on the x-axis (0 to 10). Multiple colored lines represent different voltage rails, showing a step-up transition starting at 4ms.

1. Select or deselect all loops
2. Assign colors to all loops automatically
3. List of all loops for Vout control
4. Device title text
5. Loop title text
6. Vout voltage setting
7. Margin high setting & percentage above Vout
8. Margin low setting & percentage below Vout
9. Real time voltage display. Updated every second
10. Set Vout voltage using VOUT\_COMMAND
11. Turn on selected devices using OPERATION group command
12. Immediate Turn off selected device using OPERATION group command
13. Soft Turn off selected devices using OPERATION group command
14. Margin voltage high on selected devices
15. Margin voltage low on selected devices

## 21 Group Sequencing Control

Sequencing control allows the user to edit TON\_DELAY, TON\_RISE, TOFF\_DELAY, and TOFF\_FALL of all loops at once and visualize their relationship graphically.

Device	Loop	TON_DELAY (ms)	TON_RISE (ms)	TOFF_DELAY (ms)	TOFF_FALL (ms)
R3581	Loop 1	3	3	3	3
R3581	Loop 2 n/a	0	0	0	0
R3581	Loop 1	3	3	3	3
R3581	Loop 2 n/a	0	0	0	0
R38063	VTT	3	3	3	3
R38063	VPP	3	3	3	3
R38063	3V3	3	3	3	3
R38063	5V0	3	3	3	3

1. Select or deselect all loops
2. Assign random colors to all loops automatically
3. Select or deselect individual loop
4. Set color to each Vout trace
5. Device title text copied from device manager tree view.
6. Loop title text copied from device manager tree view.
7. TON\_DELAY setting
8. TON\_RISE setting
9. TOFF\_DELAY setting
10. TOFF\_FALL setting
11. TON\_DELAY in graphic
12. TON\_RISE in graphic
13. TOFF\_DELAY in graphic
14. TOFF\_FALL in graphic
15. Write settings to all the devices on the selected bus.




## 22 Multi-Device Programmer

### 22.1 Important Note

- During programming, all devices must be disabled. If the programmer detects that any device is regulating, the programmer won't start.

### 22.2 User Interface



1. Device title text copied from device manager tree view
2. I2C address copied from device manager tree view. These are chip addresses before programming.
3. Click to load a configuration file
4. Select/deselect programming the user section or select/deselect individual device
5. Select/deselect programming the MFR section or select/deselect individual device
6. Trim section MTP left
7. Trim section programming result pass (green) or fail (red). Only used in special applications.
8. Trim section verification result pass (green) or fail (red). Only used in special applications.
9. User section MTP left
10. User section programming result pass (green) or fail (red)
11. User section verification result pass (green) or fail (red)
12. MFR section MTP left
13. MFR section programming result pass (green) or fail (red)
14. MFR section verification result pass (green) or fail (red)
15. CRC flags of trim, user, and MFR section after executing **Check MTP Left** or **Verify** operation. 0 = Pass; 1 = CRC error
16. Programming log area
17. Load a production file
18. Save selected configuration files to a single production file.
19. Check MTP remaining then update box 6 and 9
20. Verify selected devices and update box 8 and 11
21. Program and verify button


## 22.3 Programming Procedure

1. Click and load individual configuration file of each device or load a production file
2. Make sure all device izc communications are good (blue color). If there are any izc issues, it should be resolved before programming unless these devices are excluded from programming.
3. Click **Check MTP Left** to make sure there are MTP left.
4. Check user and MFR section of each device that you wish to configure.
5. Click **Program & Verify**
6. Review programming log if there are any failures.

## 22.4 Verify Only

1. Cycle board power
2. Load board design file
3. Make sure all izc communications are good
4. Click multi-device programmer icon
5. Click **Verify Only** button

## 23 I2C/PMBus Utility



- 'Scan i2c' sends slave addresses from 0x08 to 0x77 (skipping 0x0C because it's the ARA address) and checks if the address is ACKed.
- 'Scan PMBus' sends MFR\_ID command from address 1 to 127 and check if any IR controllers respond.
- Most IR controllers can operate at 400 KHz by default. Some devices can operate at 1MHz, but 1MHz operation register has to be enabled.

## 24

## Linear Calculator Utility




The Linear calculator is used to convert between PMBus linear format byte data and real numbers. The calculator has two separate conversion interfaces. **The top calculator** is for two bytes linear format data:

Exponent = High Byte [7:3]

Mantissa = High Byte [2:0] + Low byte [7:0]

Value = Mantissa \* (2 ^ Exponent)

The bottom calculator is for output voltage related parameters that use VOUT\_MODE [4:0] for exponent in linear format.



1. Real value to be converted
2. Convert real value to mantissa and exponent. Exponent can be preset and will not change during conversion.
3. Convert mantissa and exponent to real value
4. Mantissa
5. Exponent
6. Convert mantissa and exponent format to high byte and low byte
7. Convert high byte and low byte data to mantissa and exponent format
8. High byte
9. Low Byte
10. VOUT\_MODE exponent value of the linear format
11. VOUT\_COMMAND high byte
12. VOUT\_COMMAND low byte
13. Vout voltage
14. Convert VOUT\_COMMAND high/low byte to Vout voltage based on VOUT\_MODE exponent
15. Convert Vout voltage to VOUT\_COMMAND high/low byte based on VOUT\_MODE exponent

## 25 File Format

### 25.1 Configuration File

Each device can have its own configuration file, which contains the information required to program the device. It can come in 3 formats: 3-Column Configuration File, ATE Configuration File (AKA CRC32 Configuration File), and Intel Hex Format.

The user can save the configuration file by clicking the Device Level of a device, selecting the Register Map tab, and then clicking the "Save Config File" button. In the new dialog box, the user can select the configuration file format, set the name of the file, and select the location to save the file to.

To load a configuration file, click the Device Level of a device, select the Register Map tab, then click the "Load Config File" button. Find the targeted configuration file and click "Open".

#### 3-Column Configuration File (recommended for most users)

This file format uses 3 columns separated by white space, like 00 55 FF. The first part is the register address, the second part is the data, and the third part is the mask. Because some register bits like password cannot be verified after programming, the mask is used to indicate if the corresponding register bit needs to be verified (mask bit = 1) or ignored (mask bit = 0).

#### ATE Configuration File

This file format is most commonly used by ATE engineers. The GUI generates data in 3 columns separated by white space (similar to the 3-Column Configuration File format), but the data is formatted with hex notation and contains a CRC32 for verification purposes.

#### Intel Hex Format

This file format was created by Intel as a standard for programming devices, such as microcontrollers. Each line contains the following information:


1. Start Code – Signified by a ":" character
2. Byte Count – 2 Hex digits, indicating the number of bytes in the data field. We use 10h (16d).
3. Starting Address – Register Address from which to start programming the data.
4. Data Type – Data type of the Data Field. We use Hex Data Type, which is represented by "00h".
5. Data – The Register Data. Contains 16 2-byte pairs.
6. Checksum – Checksum calculated across all previous bytes in that line. It's calculated by summing all previous bytes together, taking the LSB, and performing a 2's complement on that value.

## 25.2 Board Design File


The board design file contains the complete board design information of all devices.

1. Register values of all devices
2. User interface settings
3. Board design components like inductors, capacitors, resistors, and power stages.

Some examples of the saved data are:



Load Model (Capacitors, Inductors, DCR, MOSFETs, Loadline)



Register Map (Configuration File)

## 26 Troubleshooting

### 26.1 Error Message: "The application failed to initialize properly (0xc0000135)."

USBXpress Driver was not installed correctly.

1. Go to your PowIRCenter Installation folder (default: "C:\IR\_PowIRCenter")
2. Double-click the folder "SiLabsDriver"
3. Double-click the file "install.cmd".

### 26.2 Error Message: "(.NET) Unable to find a version of the runtime to run this application."

A version of .NET was not installed, or was installed incorrectly.


1. Go to Start → Control Panel → Add/Remove Programs. Check that you have both of the following entries: [Microsoft .NET Framework 2.0](#) & [Microsoft .NET Framework 4.0](#). The Service Pack number does not matter.
2. If one or both are not installed, [Framework 2.0 can be found here](#) and [Framework 4.0 can be found here](#). Download and install the missing files, then retry running the program.
3. If they are installed, remove both, then download the install files using the links above. Afterwards, reinstall [Framework 2.0](#) first, then [Framework 4.0](#).



## 26.3 Issue: Cannot Update GUI

### Windows XP/7


1. Check that you are connected to the Internet. Updates require internet connectivity.
2. Check that instances of IR DPDC or PowIRCenter are not currently running.
  - a. Open the **Task Manager** by **either** pressing **CTRL+ALT+DEL** and selecting **Task Manager** or pressing **CTRL+SHIFT+ESC**.
  - b. Click the **Processes** tab.
  - c. Click **Image Name** (left-most column) to arrange processes by name.
  - d. Scroll down until you find a process called by "IR PowIRCenter.exe."
  - e. Select this process and then click **End Process**.
  - f. Repeat until all instances are gone, then try running **IR PowIRCenter** again.



## Windows 7

“Run As Administrator” Once:


1. Because of increased security measure on Windows 7, it will occasionally prevent the automatic update from happening. Because of this, always be sure to run IR PowIRCenter as Administrator by right-clicking the icon on your Desktop and selecting the option “Run as administrator”.




OR

Set “Run As Administrator” Permanently:

1. Right-click the icon on your Desktop and select **Properties**.



2. Select **Compatibility** and check the option “Run this program as an administrator.”




Now it will run it as an Administrator without your needing to right-click the shortcut and select the option.


## 26.4 Issue: Cannot Communicate with the Chip (I2C / PMBus)

Check that the GUI can connect to the USB005 dongle. In the bottom left of the GUI, there are three status boxes.


If the left-most cell is red, that means that the GUI and USB005 are not connected. Continue to [step 1](#).




If the left-most cell is green, but the middle cell reads "HW: USBxxxX" and the right cell reads "FW: 0.0", this means the USBXpress Driver has installed correctly, but you do not have the right driver version in your IR PowIRCenter folder. Continue to [step 3](#).




If the left-most cell is green, the middle cell reads "HW: USB005A", and right cell **does not** read "FW: 0.0", continue to [step 4](#).




1. Check that the USB is connected to a port in the back of the computer/laptop or to an externally powered USB hub. The reason for this is that in many computers and laptops, the side and front USB ports have a reduced power supply. This can cause communication problems in our USB005 dongle.
2. Check that the USBXpress Driver is correctly installed.
  - a. Connect the board to the computer.
  - b. Open the Device Manager by clicking Start, right-clicking Computer, selecting Properties, and clicking Device Manager.






- c. Expand the section titled **Universal Serial Bus controllers**. There should be an entry named **USBXpress Device**.



If you have the **USBXpress Device**, go to Step 3.  
If there is not, you will need to reinstall the **USBXpress driver**.

- d. Navigate to your installation directory (default: "**C:\IR PowIRCenter**").
  - e. Double-click the folder called **SiLabsDriver**.
  - f. Double-click the file called "**install.cmd**". This will attempt to install the driver again.
3. The next step is to verify that the **SiUSBXp.dll** is the correct version.
- Note:** If you installed the driver through the **IR PowIRCenter Installation Package.exe**, you should be able to detect the dongle by this point. If you are still having issues, contact an IR/Infineon representative who will be able to assist you.
- a. Navigate to your **IR PowIRCenter** installation directory (default: "**C:\IR PowIRCenter**").
  - b. Find the file named **SiUSBXp.dll** in the directory.
  - c. Rename it to "**SiUSBXp.dll\_backup**".
  - d. Open a Windows Explorer window and navigate to "**C:\SiLabs\MCU**".
  - e. Double-click the folder named "**USBXpress\_SDK**"
    - i. If this folder does not exist, double-click the folder named "**USBXpress**" instead.
  - f. Double-click the folder "**Examples**"
  - g. Double-click the folder "**CP210x**"
  - h. Double-click the folder "**Windows**"


- i. There should be a file named "SiUSBXp.dll" in this folder. Copy it to your IR PowIRCenter installation directory.
- j. Relaunch the GUI and check if the left-most cell is green, the middle cell reads "HW: USB005A", and right cell **does not** read "FW: 0.0":




If it looks like the above picture, continue to step 4.

If it does not, contact an IR FAE who can help you.

4. Click the Auto Populate Device button in the top left.




This will scan the bus for any IR parts. If they are detected, they will automatically appear in the left hand column.




If nothing appears, continue with the steps below to debug the issue.


- a. Check that 3.3V power to the IR controller is connected properly and that the supply is on.
- b. Check for proper SDA, SCL, & GND connections between the USB005A and the I2C Header on the Board under Test.
- c. Check that the address is correct. To scan for the address of the device under test, click the I2C Bus button.




In the window that appears, click the “Scan I2C/PMBus Address” button.



This will scan the bus for any IR parts (skipping over any reserved addresses such as 0xA). If any parts are detected, they will appear in the window above:




If the part number is not correct, it will appear as an unknown device:




5. The I2C cable between the USB ↔ I2C Board and the I2C Header on the Board under Test should be short (i.e., 20cm or less) and the SDA, SCL, & GND lines twisted together.

## 26.5 Issue: Text is misaligned or “floats”




This issue is caused by how Windows handles Text Magnification at Medium (125%). This can be fixed by switching to Smaller (100%) or Larger (150%).

1. Right-click your desktop and select "Personalize"



2. In the bottom-left corner, click "Display"






3. You should see 3 options: Smaller – 100%; Medium – 125% (default); Larger – 150%

## Make it easier to read what's on your screen

You can change the size of text and other items on your screen by choosing one of these options. To temporarily enlarge just part of the screen, use the [Magnifier](#) tool.



4. Select either Smaller or Larger, then click "Apply". This will resize everything on your display.

## 26.6 Issue: PowIRCenter is extremely slow with the dongle plugged in.

This issue is most likely caused by plugging the dongle into a USB 3.0 port (blue socket). The problem is a bug in the USBXpress Driver and can only be resolved by plugging the dongle into a USB 2.0 port (non-blue socket).

## 26.7 Issue: GUI cannot detect devices on the bus, or Autopopulate feature does not work

There are a few possibilities for this issue:

### The USB005 dongle is plugged into a USB3.0 port.

1. Unplug the USB005 dongle if it is plugged in.
2. Check that dongle connector is not blue. If the port is blue, this indicates that it is a USB3.0 port.
3. Plug the dongle into a non-blue, USB2.0 port (these are often white or yellow).


### The device or devices are not powered.

1. Check that each device is receiving 3.3V on the Vcc pin.

## 26.8 Issue: Unable to download updates due to proxy servers requirement

If your company computers require proxy servers for internet access, it will cause the failure of downloading updates. This issue can be solved by the following steps:

1. Copy and paste "[ftp://irdpdc\\_ro:mem2011@sftp.irf.com/](ftp://irdpdc_ro:mem2011@sftp.irf.com/)" without the quotes Windows Explorer
2. Some users may see a dialog box asking for **Authentication**.




If you see this prompt, type in the following credentials:


User Name: irdpdc\_ro

Password: mem2011

3. Click the folder labeled **Proxy Server** in the FTP server.



4. Select the two config files **IR PowIRCenter Update.exe.config** and **WebUpdateClient.exe.config**, right click and **Copy to folder...**, after the dialogue pops up, navigate to your **C:\IR\_PowIRCenter**, and Click **Ok**.



5. Go to **C:\IR\_PowIRCenter**, Open **IR PowIRCenter Update.exe.config** with Notepad. Find the line says,

```
proxyaddress="http://[Your Proxy Server]:[Port Number]"
```

Follow the format and put in your proxy server address and the port number.

6. Make the same change for **WebUpdateClient.exe.config**.

Now run the IR\_PowIRCenter, you should get all the updates.

If there are other issues that are not resolved by following these steps, contact an IR FAE who may be able to assist you.

**Attention:**

Revision History

Major changes since the last revision

Page or Reference	Description of change
1.1	<ul style="list-style-type: none"> <li>Exposed the link for Microsoft .NET v4.0</li> <li>Exposed the link for Microsoft Help Documentation on how to find out your version of .NET</li> <li>Exposed the link to log into the IR FTP server. This allows the user to copy/paste the address if the link does not work.</li> <li>Changed the picture for the IR PowIRCenter Installation Package.</li> </ul>
1.2	<ul style="list-style-type: none"> <li>Added Troubleshooting section. This should help handle frequently asked questions and issues.</li> </ul>
1.3	<ul style="list-style-type: none"> <li>Updated Installation Guide to reflect USBXpress v4.0 and new Installation Flow</li> <li>Added <b>Issue: Text is misaligned or "floats"</b> to Troubleshooting section, per Ramesh Balasubramaniam's request.</li> <li>Added <b>Issue: PowIRCenter is extremely slow with the dongle plugged in.</b></li> <li>Fixed references to USBXpress driver.</li> </ul>
1.4	<ul style="list-style-type: none"> <li>Added steps to the Installation Guide to deal with IT policies.</li> </ul>
1.5	<ul style="list-style-type: none"> <li>Changed the process of downloading IR PowIRCenter</li> <li>Added <b>Issue: Unable to download updates due to proxy servers requirement</b></li> <li>Added description for loop text background color orange.</li> <li>Added solution to Microsoft Recommends when downloading Microsoft .NET Framework 4.0.</li> </ul>
1.6	<ul style="list-style-type: none"> <li>Added installation instructions for standalone (POL) version</li> <li>Clarified the instructions on some of the steps.</li> <li>Updated the Table of Contents to reflect page changes</li> <li>Updated the footer date to 2016.</li> </ul>

#### Trademarks of Infineon Technologies AG

AURIX™, C166™, CanPAK™, CIPOS™, CoolGaN™, CoolMOS™, CoolSET™, CoolSiC™, CORECONTROL™, CROSSAVE™, DAVE™, DI-POL™, DrBlade™, EasyPIM™, EconoBRIDGE™, EconoDUAL™, EconoPACK™, EconoPIM™, EiceDRIVER™, eupec™, FCOS™, HITFET™, HybridPACK™, Infineon™, ISOFACE™, IsoPACK™, i-Wafer™, MIPAQ™, ModSTACK™, my-d™, NovalithIC™, OmniTune™, OPTIGA™, OptiMOS™, ORIGA™, POWERCODE™, PRIMARION™, PrimePACK™, PrimeSTACK™, PROFET™, PRO-SiL™, RASIC™, REAL3™, ReverSave™, SatRIC™, SIEGET™, SIPMOS™, SmartLEWIS™, SOLID FLASH™, SPOC™, TEMPFET™, thinQ!™, TRENCHSTOP™, TriCore™.

Trademarks updated August 2015

#### Other Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition <2016-19-02>

Published by  
Infineon Technologies AG  
81726 Munich, Germany

© 2016 Infineon Technologies AG.  
All Rights Reserved.

Do you have a question about this document?

Email: [erratum@infineon.com](mailto:erratum@infineon.com)

AppNote Number  
Document reference AN-0035

#### IMPORTANT NOTICE

The information contained in this application note is given as a hint for the implementation of the product only and shall in no event be regarded as a description or warranty of a certain functionality, condition or quality of the product. Before implementation of the product, the recipient of this application note must verify any function and other technical information given herein in the real application. Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind (including without limitation warranties of non-infringement of intellectual property rights of any third party) with respect to any and all information given in this application note.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

For further information on the product, technology, delivery terms and conditions and prices please contact your nearest Infineon Technologies office ([www.infineon.com](http://www.infineon.com)).

#### WARNINGS

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.