

Version: 5.1

Date: 24 November 2022

#### Important Notice and Disclaimer:

No part of this document may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Nicslab. No responsibility is assumed by Nicslab for its use, nor for any infringements of patents or other rights of third parties that may result from its use. Trademarks and registered trademarks are the property of their respective owners.

This product is designated for skilled users. You are entirely responsible for (1) choosing the appropriate Nicslab products for your operation, (2) designing, validating, and testing your operation, (3) ensuring your operation meets applicable standards, and any other safety, security, or other requirements.

Copyright © 2022, Nicslab.

## Safety Note

Do not operate this product in any manner not specified by Nicslab. Failure to comply with these precautions or with specific warnings or instructions elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Nicslab assumes no responsibility for any damage caused by mishandling that is beyond normal usage defined in this manual of this product.

### Before Applying DC Power Supply

Verify that the DC power supply is in good condition and safe to use. It is imperative to use ONE DC power supply as a source power for this product and the input voltage is no more than  $\pm$  18 V, or it can impair this product. Make all connections to the unit before applying power.

#### Do Not Discard the Instrument Cover

Only authorized personnel from Nicslab should remove the instrument cover.

#### Do Not Alter the Instrument

Do not put any unauthorized parts or modify the instrument without Nicslab approval and warranty.

## **Caution**

This symbol indicates the hazard of any operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data.

## Contents

List	of Tables	4
List	of Figures	4
1.	Introduction	5
2.	Hardware	7
	Specification Conditions	7
	Hardware Requirement	7
	Box Descriptions	8
	XDAC-120MUB-R4G8 Specifications	11
	Hardware Installation	14
3.	Software and Graphical User Interface (GUI)	15
	Software Requirement	15
	Software Installation	15
	Graphical User Interface (GUI)	15
	Initializing the GUI	18
	Premium Upgrade	18
	Constant Current Mode (CC Mode)	20
	Constant Voltage Mode (CV Mode)	20
	Save and Upload	21
	Sequence Automation	23
	Record	24
	Settings	25
	Value Increment Setting	26
4.	Operating XDAC through SCPI command	27
	Python Installation (Example)	27
	Run Python Code (Example)	28
	Python Function (Example)	30
	SCPI Commands	33
5.	System Shutdown	36
6.	Troubleshooting	37
7.	Warranty	38
8.	Compliance	38
9.	Contact	38

# List of Tables

Table 1. Checklist Items	6
Table 2. Specification Conditions	7
Table 3. DAC Voltage Performance Specification	11
Table 4. Current Limit and Buffer Performance Specification	12
Table 5. Troubleshooting	37
List of Figures	
Figure 1. XDAC-120MUB-R4G8 System Diagram	6
Figure 2. Product Dimension	8
Figure 3. Front and Back Panel	9
Figure 4. GUI	16

#### 1. Introduction

Nicslab XDAC-120MUB-R4G8 system is a versatile multichannel source measurement system. The XDAC-120MUB-R4G8 supports multiple voltage/current sourcing and voltage/current measurement. The system is suitable for sourcing and measuring low-power applications from simple electronic circuits to complex photonic integrated circuits.

The XDAC-120MUB-R4G8 provides independent 120 channels controlled by Graphical User Interface (GUI) and Standard Commands for Programmable Instruments (SCPI) through an Ethernet port. The system has two modes: Constant Current (CC) ranging from 500 mA (source and sink) per channel and Constant Voltage (CV) ranging from bipolar  $\pm$  2.5 Volt,  $\pm$  5 Volt,  $\pm$  10 Volt, and  $\pm$ 18 Volt per channel (please check your feature selection).

The features for XDAC-120MUB-R4G8 in detail are:

- 16-bit voltage control.
- 16-bit current control.
- Enable voltage range configuration through software (technology that enables the user to select the output range with software without losing control of the high-resolution feature).
- Flexible output configuration with 16-bit resolution: ±2.5 V, ±5 V, ±10 V, ±18 V
   (Premium Upgrade)
- Measurement time for single channel: 15 ms.
- Intuitive GUI.
- The maximum power output per channel is 10 watts.
- Real-time voltage and current reading.
- Save function to create a database.
- Upload function to generate the registrable voltage and current pattern.
- Sequence function for continuous voltage and current.
- Short circuits protection.
- SCPI command support (Python, C#, Matlab, and LabVIEW).
- SCPI Library (Premium Upgrade).
- Windows, Mac, and Linux support.
- Ethernet port.

The XDAC-120MUB-R4G8 needs to be connected with DC Power then you can plug into the Device-Under-Test (DUT) or multi-connector first. The voltage/current can be controlled through GUI or SCPI command via Ethernet or USB (Ethernet to USB port converter).

## The system diagram is as follows:




Figure 1. XDAC-120MUB-R4G8 System Diagram

The package should include the following items:

Table 1. Checklist Items

No	Item	Qty (pc)	Checklist
1	XDAC-120MUB-R4G8 Box	1	
2	DC power line cord (Red, Green, Black)	9	
3	Multi-connector optional	1	
4	Ribbon rainbow cable optional	6	
5	Ethernet cable	1	
6	USB 2.0 Ethernet Network Adaptor	1	
7	USB flash disk	1	
8	Inside USB flash disk: a. GUI Installer b. Specification & Manual c. Test Report d. Serial key (Upgrade) e. XDAC key f. Software Library (Premium) g. Comma-separated values (CSV) template (upload, demo sequence)	1	

## 2. Hardware

## **Specification Conditions**

The operating and measurement conditions are under the following conditions:

Table 2. Specification Conditions

Items	Conditions
Room Temperature	0 ~ 40 °C
Humidity	5 ~ 80 % (No Condensing)
Power Supply Input	DC Supply Max +18 V (potential at red & green DC in).  DC Supply Min -18 V (potential at black & green DC in).  Power up minimum 72 watt (+18 V, 2 A and -18 V, 2 A power supply setting).  Required headroom 1.4 – 2 V.
Waterproof/Dustproof	To be operated under room condition
Calibration period	2 years

## Hardware Requirement

The requirements for the PC/Laptop to be used for this product installation are:

• Resolution Min. 1024 x 768 pixel

Hard disk Min. 500 MB of available free space (32-bit and 64-bit operating system)

USB Port USB 2.0

RAM Min. 2 GB

• CPU 2.4 GHz or faster

• Ethernet port or internet connection via a router.

## **Box Descriptions**

The box size is 232 (W)  $\times$  450 (L)  $\times$  102 (H) mm, as the pictures below:




Figure 2. Product Dimension

The details of the front and back panels of the box are described below:




Figure 3. Front and Back Panel

### Note:

A1	Power Switch	Turns the instrument on or off.  Caution  Before turning OFF please close the GUI or type shutdown (SCPI command) to minimize the risk of corrupting the system file (such as data loss).
A2	Indicator Light	Blue -> Power Indicator.  Green -> Serial Transfer Data Active.
A3	USB-A	USB port type A.
A4	Ethernet port	Use an ethernet cable to connect. An ethernet to USB port converter is also possible to be used if the computer doesn't have the ethernet port.
A5	Pin Output (40 channels per row)	To connect to Device Under Test (DUT) using cable or multi-connector.
		Row 1: Channel 1 to 40
		Row 2: Channel 41 to 80
		Row 3: Channel 81 to 120
A6	GPIO	You may use it for external control and monitoring directly to the microprocessor.
Α7	Input DC Max ±18V	Caution  Please follow the safety notice on your DC power supply. USE ONLY ONE DC POWER SUPPLY and the input is no more than ±18V. The XDAC will not power up if the current from the power supply is too low (minimum 2 A).  Green cable inserts to GND  Black cable inserts to -18V  Red cable inserts to +18V
A8	Airflow	For air circulation inside the box.

## XDAC-120MUB-R4G8 Specifications

The performance specifications of Digital Analog Converter (DAC) <u>voltage</u> are listed in Table 3 below:

Table 3. DAC Voltage Performance Specification

No	Parameter	Min	Тур	Max	Unit	Test conditions/comments
1	Resolution	16			Bits	
2	Integral nonlinearity (INL)	-1	± 0.5	1	LSB	All ranges, except ±2.5 V
3	Differential Nonlinearity (DNL)	-1	± 0.5	1	LSB	Specified 16-bit monotonic
4	Total unadjusted error	-0.1	± 0.01	0.1	%FSR	All ranges except ±2.5 V
5	Unipolar offset error	-0.03	± 0.015	0.03	%FSR	All unipolar ranges
6	Unipolar zero-code error	0	0.04	0.1	%FSR	All unipolar ranges
7	Bipolar zero-code error	0	0.04	0.1	%FSR	All bipolar ranges
8	Full-scale error	-0.2	± 0.075	± 0.2	%FSR	All ranges
9	Gain error	-0.1	± 0.02	0.1	%FSR	All ranges except ±2.5 V
10	Unipolar offset error drift		±2		ppm of FSR/°C	All unipolar ranges
11	Bipolar offset error drift		±2		ppm of FSR/°C	All bipolar ranges
12	Gain error drift		±2		ppm of FSR/°C	All ranges
13	Output voltage drift over time		5		Ppm of FSR	$T_A = 40$ °C, Full-scale code, 1900 hours
DYN	AMIC PERFORMANCE					
14	Output Voltage Settling Time		12		μs	$1\%$ to $3\%$ and $3\%$ to $1\%$ scale setting time to $\pm$ 1 LSB, $\pm$ 10 V range, $R_L = 5$ k $\Omega$ , $C_L = 200$ pF
15	Slew Rate		4		V/µs	All ranges except 0 to 5 V
16	Power-on glitch magnitude		0.3		V	Power-down to active DAC output, $\pm 20 \text{ V}$ range, Midscale code, $R_L = 5 \text{ k}\Omega$ , $C_L = 200 \text{ pF}$
17	Output noise		15		µV р-р	0.1 Hz to 10 Hz, Midscale code, 0 to 5 V range
18	Output noise density		78		nV/\Hz	1 kHz, Midscale code, 0 to 5 V range
19	AC PSRR		1		LSB/V	Midscale code, frequency = 60 Hz, amplitude 200 mVpp superimposed on $V_{DD}$ , $V_{CC}$ , or $V_{SS}$
20	DC PSRR		1		LSB/V	Midscale code, $V_{DD} = 5V$ , $V_{CC} = 20 V$ ±5 %, $V_{SS} = 20 V$
21	Code change glitch impulse		4		nV-s	1 LSB change around the major carrier, 0 to 5 V range
22	Channel to Channel AC crosstalk		4		nV-s	0 to 5 V range. Measured channel at midscale. Full-scale swing on all other channels.
23	Channel to Channel DC crosstalk		0.25		LSB	0 to 5 V range. Measured channel at midscale. All other channels at full-scale.
23	Digital feedthrough		1		nV-s	0 to 5 V range, Midscale code, F <sub>SCLK</sub> = 1 MHz

The performance specifications of the current buffer circuit are listed in Table 4 below:

Table 4. Current Limit and Buffer Performance Specification

No	Parameter	Min	Тур	Max	Unit	Test conditions/comments
POW	ER OP AMP CHARACTERISTICS					
1			200	600	μV	
	Input offset voltage			1000	μV	0 °C < TA < 70 °C
				1300	μV	-40 °C < TA < 85 °C
2	Input offset voltage drift	-10	-4	10	μV/°C	
3	Input offset current	-100		100	nA	$V_{CM} = 0 V$
4	Input bias current	-600	-160		nA	$V_{CM} = 0 V$
5	Input noise voltage		3		μV <sub>P-P</sub>	
6	Input noise voltage density		15		μV/\Hz	
7	Input noise current density		3		pA/\Hz	
_			500			Common mode
8	Input resistance		100			Differential mode
9	Input capacitance		6		pF	Pin 8 and Pin 9 to Ground
4.0		-14.5		13.6	V	Typical
10	Input voltage range	-12.0		12.0	V	Guaranteed by CMRR test
11	Common mode rejection ratio	92	105		dB	-12 V < V <sub>CM</sub> < 12 V
	Power supply rejection ratio	90	100		dB	$V_{EE} = V_{-} = -5 \text{ V}, V_{CC} = V_{+} = 3 \text{ V to } 30 \text{ V}$
10		110	130		dB	$V_{EE} = V_{-} = -5 \text{ V}, V_{CC} = 30 \text{ V},$ V+ = 2.5 V to 30 V
12		90	100		dB	$V_{EE} = V_{-} = -3 \text{ V}, V_{CC} = V_{+} = 5 \text{ V}$
		110	130		dB	$V_{EE} = -30 \text{ V} - = -2.5 \text{ V to } -30 \text{ V}$ $V_{CC} = \text{V} + = 5 \text{ V}$
13	Large-signal voltage gain	75			V/mV	$R_L = 1 \text{ k}\Omega$ , -12.5 V < $V_{OUT}$ < 12.5
		40			V/mV	$R_L = 100 \ \Omega$ , -12.5 V < $V_{OUT}$ < 12.5 V
		5			V/mV	$R_L = 10 \ \Omega$ , -5 V < V <sub>OUT</sub> < 5 V, V+ = -V- = 8 V
14	Output sat voltage low		1.9	2.5	V	$V_{0L} = V_{OUT} - V_{-}$ $R_{L} = 100, V_{CC} = V_{+} = 15 \text{ V}, V_{E}$ $= V_{-} = -15 \text{ V}$
15	Output sat voltage high		1.7	2.3	V	$V_{OH} = V + - V_{OUT} \\ R_L = 100, V_{CC} = V + = 15 V, \\ V_{EE} = V - = -15 V$
1/	Outout about simultaneous	500	800	1200	mA	Output Low, $R_{SENSE} = 0 \Omega$
16	Output short-circuits current	-1000	-800	-500	mA	Output High, $R_{SENSE} = 0 \Omega$
17	Slew rate	0.7	1.6		V/µs	
18	Full power bandwidth	11			kHz	V <sub>OUT</sub> = 10 V <sub>PEAK</sub>
19	Gain bandwidth product		3.6		MHz	f = 10 kHz

20	Settling time		8		μV	0.01 %, $V_{OUT} = 0 \text{ V to } 10 \text{ V}$ , $AV = -1$ , $R_L = 1 \text{ k}\Omega$
CURF	RENT SENSE CHARACTERISTICS				'	<u>'</u>
21	Minimum current sense voltage	0.1		10	mV	$VC_{SRC} = VC_{SNK} = 0 V$
22	Current sense voltage 4% of the full scale	15	20	25	mV	$VC_{SRC} = VC_{SNK} = 0.5 V$
23	Current sense voltage 10% of the full scale	45	50	55	mV	$VC_{SRC} = VC_{SNK} = 0.5 V$
24	Current sense voltage 100% of the full scale	480	500	520	mV	$VC_{SRC} = VC_{SNK} = 5 V$
25	Current limit control input bias current	-1	-0.2	0.1	μΑ	VC <sub>SRC</sub> , VC <sub>SNK</sub> Pins
26	SENSE- input current	-500		500	nA	0 V < (VC <sub>SRC</sub> , VC <sub>SNK</sub> ) < 5 V
27	FILTER input current	-500		500	nA	0 V < (VC <sub>SRC</sub> , VC <sub>SNK</sub> ) < 5 V
		-500		500	nA	$VC_{SRC} = VC_{SNK} = 0 V$
28	SENSE+ input current	200	250	300	nA	$VC_{SRC} = 5 V$ , $VC_{SNK} = 5 V$
20	SENSE+ input current	-300	-250	-200	nA	$VC_{SRC} = 0 V$ , $VC_{SNK} = 5 V$
		-25		25	nA	$VC_{SRC} = VC_{SNK} = 5 V$
29	Current sense change with output voltage		±0.1		%	$VC_{SRC} = VC_{SNK} = 5 \text{ V}, -12.5 \text{ V}$ < $V_{OUT} < 12.5 \text{ V}$
	Current sense change with supply voltage		±0.05		%	$VC_{SRC} = VC_{SNK} = 5 \text{ V}, 6 \text{ V} < (V_{CC}, V+) < 18 \text{ V}$
30			±0.01		%	2.5 V < V+ < 18 V, VCC = 18 V
			±0.05		%	-18 V < (V <sub>EE</sub> , V-) < -2.5 V
			±0.01		%	-18 V < V- < -2.5 V, V <sub>EE</sub> = -18 V
31	Current sense bandwidth		2		MHz	
32	Resistance FILTER to SENSE-	750	1000	1250	Ω	
LOGI	C I/O CHARACTERISTICS					
33	Logic output leakage			1	μΑ	V = 15 V
34	Logic low output level		0.2	0.4	V	I = 5 mA
35	Logic output current limit		25		mA	
36	Enable logic threshold	0.8	1.9	2.5	V	
37	Enable pin bias current	-1		1	μΑ	
38	Total supply current		7	13	mA	V <sub>CC</sub> , V+ and V-, V <sub>EE</sub> connected
39	V <sub>CC</sub> supply current		3	7	mA	$V_{CC}$ , V+ and V-, $V_{EE}$ separate
40	Supply current disabled		0.6	1.5	mA	V <sub>CC</sub> , V+ and V-, V <sub>EE</sub> connected, V <sub>ENABLE</sub>
41	Turn-On delay		10		μs	
42	Turn-Off delay		10		μs	

#### Hardware Installation

This section describes how to install XDAC-120MUB-R4G8 and how to connect your Device Under Test (DUT) to the output terminals.

The steps are as follows:

- 1. Precondition step: connect to the DC power supply (max  $\pm 18$  V). Make certain that the DC power supply is always 'ON'.
- 2. Connect an Ethernet cable to your workstation (PC/Laptop) via Ethernet Port or USB 2.0 Ethernet Network Adaptor.
- 3. Install the software/GUI (see the Software Installation section) from the flash disk or Dropbox link.
- 4. Turn ON the switch.
- 5. Wait until there is Blue light (the system is ready to use).
- 6. You may now open the GUI.
- 7. Connect XDAC output to your Device Under Test (DUT).

## 3. Software and Graphical User Interface (GUI)

## Software Requirement

The GUI software is suitable for the following operating systems:


- Windows<sup>®</sup> 7 (32-bit, 64-bit).
- Windows<sup>®</sup> 10 (32-bit, 64-bit).
- Windows<sup>®</sup> 11 (64-bit).
- · macOS Big Sur.

#### Software Installation

The first step is to install the XDAC\_setup.exe file into your computer, then double-click to launch the GUI. The icon is as below:



At the end step of the installation, check a 'Create a desktop shortcut'.



Double-click the executable GUI icon (as shown below) on your desktop to launch the GUI.



### Graphical User Interface (GUI)

Start the XDAC by pressing the ON button, then you can control it by GUI. the display details are on the next page.

First, set up the connection to your instruments by entering the IP address. Please scan the XDAC IP address to know the XDAC IP. The XDAC IP address should appear if you scan it in the local network using an IP scanner such as Angry IP Scanner or NMAP.




Figure 4. GUI

#### Note:

Callout	Description						
B1	ON/OFF Switch						
B2	Save File Button - Premium Feature						
В3	Upload File Button - Premium Feature						
B4	Auto Feature Sequence: Upload Table Button   CV Mode - Premium Feature						
B5	Auto Feature Sequence: Upload Table Button I CC Mode - Premium Feature						
В6	Auto Feature: Run Button CV and CC Mode separately - Premium Feature						
B7	Auto Feature: Run Button CV and CC Mode combined - Premium Feature						
B8	Number of the Sequence - Premium Feature						
В9	Record Data Button - Premium Feature						
B10	<ol> <li>Setting for:         <ol> <li>Set Limit voltage and current values - Premium Feature</li> <li>V Range (16-bit precision for every range of voltages: ±2.5, ±5, ±10, ±18 V) - Premium Feature</li> </ol> </li> <li>Set Reading speed of Voltage and Current (Fast, Medium, Slow) - Premium Feature</li> </ol>						
B11	Increment Settings						
B12	Status of connection						
B13	ON/OFF Button for the current Tab						
B14	Enable/Disable (Lock) Channel Controller for all channels in current tab						
B15	Text area to set the voltage for all channels in current tab						
B16	Slider to set the voltage for all channels in current tab						
B17	Text area to set the current for all channels in current tab						
B18	Slider to set the voltage for all channels in current tab						
B19	Upgrade Button						
B20	Notes - Premium Feature						
B21	Current Settings Slider						
B22	Current Value Based on Increment Setting						
B23	Voltage Settings Slider						
B24	Voltage Value Based on Increment Setting						
B25	Current Value						
B26	Voltage Value						
B27	Enable/Disable (Lock) Channel Controller						
B28	Number of channels						
B29	ON/OFF Button per Channel						
B30	Tab Channel						

## Initializing the GUI

This section shows how to initialize the GUI:

- 1. Launch the program by double-clicking the "XDAC\_setup\_exe" icon.
- 2. Enter XDAC's IP address and XDAC key as given. If the connection is successful, then the GUI will open and there is the Green indicator light.



3. Press the 'ON/OFF' button (B1) to start the GUI.



4. Turn ON (B29) on each channel to the input voltage and current values.




## Premium Upgrade

This section shows how to upgrade the GUI to enable advanced features.

1. Press the upgrade button at the top right corner of the window



2. After the upgrade window opened, input the Premium Upgrade Key.



3. If your Premium Upgrade Key is valid, you will get a message that indicates a successful upgrade.



- 4. You can use several features that were previously locked
  - Save
  - Upload
  - CV Mode
  - CC Mode
  - CCvCV Mode
  - Record
  - Setting
    - Set Limit Voltage
    - Set Limit Current
    - Set Voltage Range
  - Notes


The next few sections are the advanced features that are enabled after upgrading the GUI.

### Constant Current Mode (CC Mode)

This section shows how to do CC mode according to your purpose:

To do CC mode, you need to move the voltage slider (B23) or adjust the voltage value (B24) to a certain value before setting the current value on (B22) or slider (B21). As an example, channels 1 to 5 in the below picture were given 120  $\Omega$  load.

Important note: When you manually input the values, always press 'Enter'.



## Constant Voltage Mode (CV Mode)

This section shows how to do CV mode according to your aim:

To do CV mode, you need to move the current slider (B21) or adjust the current value (B22) to a certain value. Then adjust the voltage value on (B24) or slider (B23). You may also adjust the current settings or current slider to the maximum value (500 mA).

Important note: When you manually input the values, always press 'Enter'.




## Save and Upload

The CSV file (.csv) resulting from the Save function can be uploaded again through the Upload button (B3). You may also create your own CSV file of voltage and current and upload it later.


1. To save the configuration, click the 'Save' button (B2).



2. Select a directory and write the file name.



- 3. The file will be saved as a .csv file.
- 4. Check the .csv file that you have saved.




The voltage, current, and notes are recorded.


5. To upload the configuration, click the 'Upload' button (B3).



6. Choose and open the intended file.



7. It will upload the configuration like the previous configuration.




Note: When you upload CV mode, the current setting slider values automatically show 2184.50 bits to open the current flow from the supply. You may adjust this to match your requirements.

### Sequence Automation

Sequence is the setting that automates the determined values of current (mA) or voltage (V) given the certain Delay Time (in milliseconds).

1. The template of the Sequence is given, then you need to input your intended values of CC Sequence (maximum 500 mA), CV Sequence (± 18 V), and Delay Time (in milliseconds). Set the delay time to more than 2 seconds to have more accurate values. To have a faster response (switching time) you can set it via the SCPI command.



#### Note:

- A. Template given for CC and CV sequences.
- B. Input your intended values according to the modes (CC: 500 mA, CV: ±18 V).
- 2. Upload the .csv file of sequence by pressing CC Sequence (for CC Mode) and CV Sequence (for CV Mode).
- 3. After uploading, choose sequence mode by clicking either 'Run CV' (B6 Mode for CV sequence), 'Run CC' (B6 Mode for CC sequence), or 'Run CCCV' (B7 Mode for both CC and CV sequences).


**Important note**: when 'Run CCCV' use the <u>same delay time</u> on the template .csv of CC and CV sequence.

#### Record


'Record' (B9) keeps data on voltage and current values. The record starts by the time you click the Record button and finish when you click again the same button. Put the file in any directory and click save.



Click the same button to stop Recording. After that, put the file in any directory



This is the output of the recorded file




## Settings


Click the 'Settings' button (B10).




The 'Settings' feature consists of:

- Set the maximum limit for both current and/or voltage values
- Set the range for voltage values where you can choose the voltage range to limit the voltage values (B23, B24, and B26), the range of voltages are ±2.5 V, ±5 V, ±10 V, and ±18 V. Each range has 16-bit precision.
- Set the reading speed to adjust different speeds for reading voltage and current. The speed is based on averaging the number of sample output values.





Important note: When you input the values, always press 'Enter'.




Reading Speed



## Value Increment Setting

In this setting, the value of the voltage and current can be incrementally changed from a minimum of 0.001 to 1. Adjust the arrow to increase and decrease the value increment (B11).



## 4. Operating XDAC through SCPI command


This section set guidelines to help you develop a program for any language that suits you best. As an example, we give the Python example.

## Python Installation (Example)

Please follow the steps below for dynamic programming using the SCPI command through Python via TCP/IP.

The following Python versions and packages need to be installed:


- 1. Python 2.7 or Python 3.X (download and install the latest version from <a href="www.python.org">www.python.org</a>). \*Tested with Python 3.9.
- 2. PyCharm 2017.3.4 or the latest version (download and install the latest version from <a href="https://www.jetbrains.com/pycharm/">https://www.jetbrains.com/pycharm/</a>)




## Run Python Code (Example)

To run the Python code please follow the steps below:


1. Open PyCharm software and open file example (e.g XDAC-8MUB-R4G8-SMA.py)




2. Configure the Python interpreter (see figure below) by clicking Configure Python Interpreter link on the drop-down menu, or in File >> Settings >> Project Interpreter.



- 3. Install additional packages, for example enum34, by:
  - A. Clicking '+' button
  - B. Search and choose enum34
  - C. Install all the packages.



4. The packages for the Python Interpreter are listed in the green rectangle.



- 5. Select Python Configuration and choose the file name.
- 6. Run the file by clicking the green arrow button on the top right corner to test the XDAC (Please refer to the code and SCPI commands references).

## Python Function (Example)

#### 1. <u>Input IP Address</u>

```
XDAC IP = "169.254.xx.xx"
```

#### 2. Unlock and Lock XDAC

```
print(unlock("XDACkey"))
lock()
```

note: You must unlock your XDAC first before you can use

#### 3. Set XDAC voltage range for all channels and measurement mode

```
setXDAC(voltRange, voltReadingMode, currentReadingMode)
voltRange (int list): List for all channels range
voltReadingMode (string): "FAST" or "MEDIUM" or "SLOW"
currentReadingMode (string): "FAST" or "MEDIUM" or "SLOW"
Example:
AllRValues = [5, 5, 6, 7,5, 5, 7,4]
setXDAC(AllRValues, "FAST", "SLOW")
```

### 4. Set Voltage for single channel

```
setChannelVoltage(channel, voltageVal)
channel (int): channel number
voltageVal (float): -18 - +18 V
Example:
SetChannelVoltage(1, 15)
#Set voltage to 15 V In channel 1
```

### 5. <u>Set Current for single channel</u>

```
setChannelCurrent(channel, currentVal)
channel (int): channel number
currentVal (float): 0 - 500 mA
```

```
Example:
```

```
SetChannelCurrent(1, 200)
```

#Set current to 200 mA in channel 1

### 6. <u>Set Voltage Range for single channel</u>

```
setChannelVoltangeRange(channel, range)
channel (int): channel number
range (int): 4 - 7

Description:
4: -2.5 - 2.5 V
5: -5 - 5 V
6: -10 - 10 V
7: -18 - 18 V
```

### 7. <u>Set for all channels</u>

```
setVoltageAllChannels(AllVValues)
AllVValues (float array): voltage values in an array(V)
setCurrentAllChannels(AllCValues)
AllCValues (float array): current values in an array (mA)
setRangeAllChannels(AllRValues)
AllRValues (float array): range values in an array
Example:
AllCValues = [100, 150, 100, 50, 200, 10, 10]
AllVValues = [20.1, 2.5, 13.0, 4, 5, 10.5, 9.5, 22]
AllRValues = [5, 5, 6, 7,5, 5, 7,4]
setRangeAllChannels(AllRValues)
setVoltageAllChannels(AllVValues)
```

#### 8. <u>Set OFF for single channel</u>

```
setOff(channel)
channel (int): channel number
```

### 9. <u>Set averaging method and count for measurement</u>

```
setReadingModeVoltage(mode, count)
setReadingModeCurrent(mode, count)
count (int): number of measurements to be averaged
mode (string): "MOVING" or "REPEAT"

Example:
mode: "MOVING", count: 5
#n : read #n from sensor
[#1, #2, #3, #4, #5] \Rightarrow averaged \Rightarrow reading #1
[#2, #3, #4, #5, #6] \Rightarrow averaged \Rightarrow reading #2
mode: "REPEAT", count: 5
#n : read #n from sensor
[#1, #2, #3, #4, #5] \Rightarrow averaged \Rightarrow reading #1
[#6, #7, #8, #9, #10] \Rightarrow averaged \Rightarrow reading #2
```

### 10. Read voltage or current for single channels

```
readSingleChannelVoltage(channel)
readSingleChannelCurrent(channel)
channel (int): channel number
Return value of voltage or current in one channel
```

#### 11. Read measurement values for all channels

```
readAllChannelVoltage()

Return list of voltage from all channels

readAllChannelCurrent()

Return list of current from all channels
```

## 12. Set one channel to run automatically and record it

```
sweepOne(channel, seqValueV, seqValueC, duration)
channel (int): channel number
seqValueV: voltage values in an array (V)
seqValueC: current values in an array (mA)
duration (int): duration in seconds
```

#### 13. Shutdown

shutdown()

#### **SCPI Commands**

The XDAC can be controlled using Standard Commands for Programmable Instruments (SCPI).

## Description: Unlock XDAC by XDAC Key

Format:

GETINFO: KEY

Example 1: Unlock XDAC with XDAC Key: nicslab.

GETINFO:nicslab

#### Description: Lock XDAC

Format:

LOCK

### Description: Set output voltage for single channel

Format:

SETV: CHANNEL: VOLT

Example 1: Set the output of channel 1 to 18 V.

SETV:1:18

Example 2: Set the output of channel 3 to -12.5 V.

SETV:3:-12.5

### <u>Description: Set output current for single channel</u>

#### Format:

SETV: CHANNEL: CURRENT

Example 1: Set the output of channel 1 to 500 mA.

SETC:1:500

Example 2: Set the output of channel 3 to 50 mA.

SETC:3:50

### Description: Set output voltage range for single channel

#### Format:

SETR: CHANNEL: RANGE

Range (int): 4 - 7

4 = -2.5 - 2.5 V

5 = -5 - 5 V

6 = -10 - 10 V

7 = -18 - 18 V

Example 1: Set the voltage range of channel 1 from -18 to 18 V.

SETR:1:7

#### Description: Read voltage of a single channel

#### Format:

MEASV: CHANNEL

Example 1: Get the voltage output of channel 1

MEASV:1

## Description: Read current of single channel

#### Format:

MEASC: CHANNEL

Example 1: Get the current output of channel 1

MEASC:1

## Description: set averaging mode and count of voltage measurement

Format:

MEASV: MODE: COUNT

Example 1: Set voltage measurement averaging to repeat mode and count 100.

MEASV:REPEAT:100

Example 2: Set voltage measurement averaging to moving mode and count 5.

MEASV:MOVING:5

## Description: Set zero voltage for a single channel

Format:

ZERO: CHANNEL

example: Set zero of channel 1

ZERO:1

## Description: Shutdown System

Format:

EXIT

## 5. System Shutdown

This section describes how to shut down the XDAC-120MUB-R4G8.

In the case of using GUI, the steps are as follows:

- 1. Set OFF all the channels in the GUI.
- 2. Press the ON/OFF Button in GUI (B1, Figure 4). It will change the color of the button from green to grey.
- 3. Close the GUI application (it will soft shut down the program inside the XDAC-120MUB-R4G8).
- 4. Press the power switch (A1, Figure 3).
- 5. Turn off or disconnect the DC Power Supply.

In the case of using SCPI Command, the steps are as follows:

- 1. Use setOff (channel) function to set off the channel used before.
- 2. Use lock() and shutdown() functions to soft shut down the program inside the XDAC-120MUB-R4G8.
- 3. Press the power switch (A1, Figure 3).
- 4. Turn off or disconnect the DC Power Supply.

NOTE: Once the soft shutdown occurred, the Blue led will be turned off, and XDAC-120MUB-R4G8 cannot directly be used again, since the system is not ready (refers to Hardware Installation clause 7). To use XDAC-120MUB-R4G8 after a soft shutdown occurred, restart the power from DC Power Supply (using button A8 or unplug and plug the DC Power Supply).

# 6. Troubleshooting

Please use the following guidelines to identify a particular problem. If the solution does not rectify the problem, contact us at <a href="mailto:support@nicslab.com">support@nicslab.com</a>.

Table 5. Troubleshooting

Problem	Cause	Solution
Failed to connect at GUI	The DC power supply is OFF	Turn ON the DC power supply and switch ON the power
Failed to connect at GUI	The switching power is OFF	Switch ON the power
Failed to connect at GUI	No Green light (no data transfer)	Restart the GUI
The Green light offs when software is active or software freeze	Initialization failed	Restart the software, or unplug - plug the USB/Ethernet connector, or Press the Reset Button
No channel output detected at the device under test	Connection failed	Check the metal pad checkpoint to the intended channel
Unable to upload the file	File format problem	Make sure the file format is .csv
No value after uploading the file	File problem	Check the file content, and make sure there is no blank space on each row.
Unable to use the Auto Mode feature	File format problem	Check file format. It should be a CSV file. Check content format

## 7. Warranty

Nicslab warrants the hardware and software designed by Nicslab to work accordingly, fulfilling the highest standard of a quality product. Nicslab is not liable for consequential or incidental damages for errors in subject to misuse, neglect, accident, modification, use in critical operation, or has been soldered or altered in any way outside stated by us or unauthorized maintenance.

Nicslab retains to change the material and technical data of this manual at any time without notice, in future editions.

Please do not hesitate to contact us at support@nicslab.com if you would like to have more information on the warranty or return and refund policy.

## 8. Compliance

This product complies with the requirements of the European Union's *Conformite Europenne* (CE) and Restriction of Hazardous Substances in Electrical and Electronic Equipment (RoHS) Directive 2015/863 (RoHS3). The certificates can be accessed <u>here</u>.

### 9. Contact

#### **United States**

Nicslab, Ops Inc.

228 Hamilton Avenue, 3rd Floor, Palo Alto

Silicon Valley, CA, 94301

Phone number: +1 (650) 798-5000

WhatsApp: +1 (650) 613-2494

Email: support@nicslab.com

Website: www.nicslab.com.

#### Indonesia

PT. Nicslab Global Industri

Wisma Monex 9th floor

Jl. Asia Afrika No. 133-132, Bandung West Java 40112

Phone: +62 22 8602 6854

Email: nicslab.id@nicslab.com

Book Meeting here.