● Part Numbering

Ferrite Core

(Part Number)   **FS** **RB** **12** **1** **060** **RT** **B0** **0** **T**
❶ ❷ ❸ ❹ ❺ ❻ ❼ ❽ ❾

❶Product ID

Product ID	
FS	Ferrite

❷Series

Code	Series
RH	Beads Core
RB	Ring Core
RC	for Flat Cable
SA	Plate Core

❸Dimensions (Example)

Code	Dimensions
12	Approximately 12mm
05	Approximately 5mm

❹Outer Dimension Supplement Code

Code	Outer Dimension Supplement Code
0	Serial number is added in case their internal diameters are not the same.

❺Length (Example)

Code	Length
120	12.0mm
050	5.0mm
A50	1.50mm
B50	2.50mm
Z50	0.50mm
Z55	0.55mm

Expressed by three figures or combination of a letter and two figures. A to J (Except for I) indicates one to nine. Z indicates Zero.

❻Material

Code	Material
RN	Ni-Zn μ=550
RT	Ni-Zn μ=1600
RX	Ni-Zn μ=750

❼Process

Code	Process
00	Standard Type
B0	Barrel Type
N0/N3	Two or more cores Type

❽Individual Specification Code

Code	Individual Specification Code
0	Standard Type

❾Packaging

Code	Packaging
B	Bulk
S	Sheet
T	Tray