

ASSEMBLING THE CLAW

Assemble the claw as shown in the diagram below.
The screws should self-tap into the acrylic.

Take care when screwing in the servo screws as you can damage the wires!

Note: Ensure the servo is almost at its maximum travel, counter clockwise, when attaching the claws.

