



# ENGINEERING SPECIFICATION

## INSTALLATION INSTRUCTION SHEETS

### 1.0 SCOPE

This specification consists of installation instructions for the Self Contained Power Connector for tap splice.

### 2.0 PURPOSE

To define material number system for the above instructions.

### 3.0 REFERENCE MATERIAL NUMBERS

See pages 2-3 for the actual instruction sheets. These pages can be used as originals.

### 4.0 DEFINITIONS

Not applicable.

### 5.0 PROCEDURES

Place one (1) instruction sheet in the smallest unit container.

### 6.0 IMPLEMENTATION

December 6, 2005

<u>REVISION:</u> <b>D</b>	<u>ECR/ECN INFORMATION:</u> <b>EC No: WNA2009-0564</b> <u>DATE:</u> <b>2009 / 03 / 04</b>	<u>TITLE:</u> <b>SELF CONTAINED POWER CONNECTOR INSTALLATION INSTRUCTIONS FOR TAP SPLICE</b>	<u>SHEET No.</u> <b>1 of 3</b>
<u>DOCUMENT NUMBER:</u> <b>SD-19402-004</b>	<u>CREATED / REVISED BY:</u> <b>ETHRODAHL</b>	<u>CHECKED BY:</u> <b>JMACNEIL</b>	<u>APPROVED BY:</u> <b>JMACNEIL</b>
TEMPLATE FILENAME: ENGINEERING_SPEC(SIZE_A)(V.1).DOC			

# COC-3 Self Contained Power Connector Installation Instructions For Tap Splice

The 2-circuit-with-ground tap connector is used to tap non-metallic-sheathed cable in the following wire ranges and types:

Wire Range AWG	Description	Order No.	Optional Bench Arbor Press	Optional Hand Tool
12-14	Self Contained Power Tap Connector - 2 circuit w/ ground for solid wire	19402-1000 (COC-3)	64006-0200	19285-0074



## Reference Information

UL File Number: E182087

CSA File Number: LR18689-C53

NEC Article: 550, 551, and 545

HUD Section: 3280.801


Current: 20A

Voltage: 300V

## Installation Procedure:


1. Carefully strip sheath and paper coverings and prepare the wires to the configuration as shown in **Figure 1**. For reference in the absence of a measuring tool, the distance shown in **Figure 1.1** is approximately equal to strip length.
2. Hold the clear strain relief cover with bottom facing upward as shown in **Figure 2**.
3. Lay wire into locator slots, making sure the black wire is placed into locator slots marked BLK shown in **Figure 2**. Use the two wire locators and spreaders to help guide the wire into place. Press the cable sheath into the integral strain relief slot.
4. While holding the strain relief cover, position the housing's hinge posts into the hinge slots and press down until both lock into place as shown in **Figure 2**.
5. Close the strain relief cover and housing by hand. Place the connector assembly into Molex tool as shown in **Figure 3**. Squeeze the tool until the connector bottoms out and the locking latches engage on both sides. OR alternately, squeeze the top and bottom closed with tongue and groove pliers as shown in **Figure 3.1**. Pliers must be a minimum of 10" long. Squeeze firmly on both sides, squarely across the connector with the bottom jaw of the pliers butted up against the T-extension in the housing to ensure wires seat completely into slots.
6. Inspect the connector to ensure the wires have been properly engaged into the housing assembly contacts. A properly terminated wire is fully seated into its proper slots with no significant bow of the cover. If the wires are not properly seated into the housing assembly contacts, the wires must be re-terminated with a NEW CONNECTOR. Once the cover has been closed the connector cannot be re-used. Failure to comply with this procedure may result in the failure of the connector.

**Fig. 1 Cable prep**




**Fig. 1.1**


**Reference Dimension for Strip Length**




**Fig. 2**  
**Attach housing to strain relief.**



**FIG. 3.1** Alternately, clamp connector with tongue & groove pliers, squeezing squarely and firmly approximately as shown.






OR





10	9	
MATERIAL NO.	ENGINEERING P/N	
194021000	COC-3	


191402



HOUSING ASSEMBLY  
MATERIAL NUMBER 19402-2000  
CONTAINING HOUSING P/N 19402-3000,  
COLOR NATURAL



COVER (C)  
MATERIAL NUMBER 19402-3110, CLEAR



## ASSEMBLED VIEWS

## NOTES:

1. PARTS ARE PACKAGED 50 UNITS PER CONTAINER.
  2. REF: UL FILE NO. E182087, CSA FILE NO. LR18689.
  3. PARTS ARE ROHS COMPLIANT.

CHANGE COVER P/N EC NO: WNA2009-0564 DRWNE/THRODAHL CHKD:J/MACNEIL APPR:J/MACNEIL 2009/05/22	QUALITY SYMBOLS  ▼=0 △=0	GENERAL TOLERANCES (UNLESS SPECIFIED)		DIMENSION STYLE IN/MM		SCALE 1:1	DESIGN UNITS INCH	THIRD ANGLE PROJECTION
		mm	INCH	DRAWN BY 4 PLACES $\pm$ ---	DATE DAY	1997/05/27	TITLE CUSTOMER DRAWING COC-3 SC TAP CONNECTR ASSEMBLY 12-14AWG SOLID 2/C+GRD	
DESCRIPTION  REV:		3 PLACES $\pm$ ---		$\pm$ .005	CHECKED BY 2 PLACES $\pm$ 0.13	DATE RDEROSS	1997/05/27	molex MOLEX INCORPORATED
		2 PLACES $\pm$ 0.13		$\pm$ .01	APPROVED BY 1 PLACE $\pm$ 0.25	DATE RDEROSS	1997/05/27	
		ANGULAR $\pm$ ---			MATERIAL NO. SEE CHART		DOCUMENT NO. SD-19402-105	SHEET NO. 1 OF 1
		DRAFT WHERE APPLICABLE MUST REMAIN WITHIN DIMENSIONS			SIZE B	THIS DRAWING CONTAINS INFORMATION THAT IS PROPRIETARY TO MOLEX INCORPORATED AND SHOULD NOT BE USED WITHOUT WRITTEN PERMISSION		