



- Assembly Guide F15542_FLORENCE-3R-IP-Z90
1. Insert Silicone sealant into bottom of FLORENCE-3R-IP-Z90 lens
 2. Set lens and silicone sealant on top of PCB
 3. Fasten lens to heatsink with 14pcs of M3 screws
- Screw type DIN 7985 M3, Max torque 0.6Nm

Tolerances if not otherwise shown According to DIN ISO 2768-1 Linear measures: Up to 30mm class M, otherwise class C. According to DIN ISO 2768-2 Form and position: class L		LEDiL LediL Oy Salorankatu 10 FIN 24240 SALO Finland	
THIRD ANGLE PROJECTION:		DRAWING TITLE Datasheet_FLORENCE-3R-IP-Z90	
This drawing is the property of LEDiL Oy. It may not be reproduced, copied or communicated without a written agreement with LEDiL Oy.		SIZE A2	PART NUMBER F15542
		SCALE 1:1	WEIGHT g
		SHEET 1/1	