TILT – 50A

Dual–Axis Dynamic Inclinometer

Three-Axis Accelerometer Three-Axis Gyroscope

Datasheet





Specifications –	electrical
Power source	4.1 – 38 VDC
Measuring range	Pitch: ±90°, Roll: ±180°
Resolution	0.025° 0.5 mg (@ data rate ≤ 5)
Zero offset error [†]	$< \pm 0.1^{\circ} (@20^{\circ}C)^{\dagger}$, maximum offset
	drift is ±0.011° /°C
Accuracy	≤ 0.15° Static
(typical)	≤ 1.0° Dynamic (RMS)
Accelerometer range	±2 g/±4 g/±8 g selectable
	Default: ±4g
Gyroscope range	±250/500/1000/2000°/s selectable
	Default: ±500°/s
Baud rate	2.4kbps – 921.6kbps selectable,
	default: 115.2kbps
Data format	ASCII, port settings: 1 start bit, 8
	data bits, 1 stop bit, no parity
Output data rate	1, 2, 5, 10, 20, 25, 40, 50, 100 and
	200 Hz selectable
LED indicators	Green: CPU heartbeat
	Flashing at 1 Hz
	Red: Data transmission rate
	Flashing at current data rate
Power consumption	< 250 mW (< 50 mA @ 5V)
GUI software	WinCTi-Tilt [®]
Serial interface	RS232, RS422, RS485, USB, SSI, 3.3V
options	TTL UART, Wireless (Bluetooth 4.2)
	RS485 with multi-drop networking
Temperature sensor	1°C
resolution	
Accessories	
Connector and cable	
MCKC 6E/CC10107	Malo cablo M8 6 nin

MSKS 6F/CS12187 Male cable M8, 6-pin

Zero g offset can be easily corrected and saved by user.

Features

- Dynamic tilt measurement
- Measuring range: Pitch: ±90°, Roll: ±180°
- Three-axis accelerometer
- Three-axis gyroscope data
- Static accuracy: ≤ 0.15°
- Dynamic accuracy: ≤ 1.0° (RMS)
- High resolution: 0.025° | 0.5 mg
- Simple ASCII interface language
- IP 67 compliant connector, cable and housing
- LED heartbeat and transmission indicators
- Robust aluminum housing
- Low power consumption: < 250 mW (< 50 mA @ 5 V)

Applications

- Dynamic platform alignment, and stabilization
- Vehicle control, ship, robot, automotive
- Tilt sensing and leveling
- Automotive safety systems
- Motion and position measurement
- Navigation and GPS compensation
- Robotics position sensing and control
- Agricultural and industrial vehicle tilt monitoring

Specifications – mechanical			
Protection	IP 67 (housing, connector and cable)		
Dimension	1.65" x 2.15" x 1.00"		
Material	Enclosure: anodized aluminum		
(cable is optional as a	Connector: brass / nickel		
third party product)	Cable molded head: TPU		
	Cable carrier: TPU or nylon		
	Conductor insulation: PVC		
Temperature range [§]	-40°C to +85°C (-40°F to +185°F)		
Connection	Cable gland		
	connector M8, 6-contact (female)		

Terminal assignment						
Connector	RS232/UART/USB ^{**}	RS422	RS485	Wire Color		
Pin 1	+Vin	+Vin	+Vin	Brown		
Pin 2	GND	GND	GND	White		
Pin 3	ТХ	TX+	D+	Blue		
Pin 4	-	TX-	D-	Black		
Pin 5	RX	RX+	-	Gray		
Pin 6	-	RX-	-	Pink		
$ \begin{array}{c} 1 & 6 \\ 2 & 2 \\ 5 & 0 & 3 \\ 4 \end{array} $	Device: M 8 – 6-contact (female)	Cable: ² M 8 – 6-pin (male) ³		$) \begin{array}{c} \begin{array}{c} \begin{array}{c} & \\ 2 \\ & \\ \end{array} \\ \begin{array}{c} \\ \end{array} \\ \begin{array}{c} \\ \end{array} \\ \begin{array}{c} \\ \\ \end{array} \\ \begin{array}{c} \\ \end{array} \\ \begin{array}{c} \\ \\ \end{array} \\ \begin{array}{c} \\ \end{array} \\ $		

[§] Cable is a third-party product with temperature tolerance from -40°C to

[‡] Units can be calibrated between -40°C and 85°C on request.

^{+105°}C (-40°F to +221°F).

^{*} USB uses UART interface and a UART to USB cable.

TILT – 50A

Three-Axis Accelerometer Three-Axis Gyroscope


Dual–Axis Dynamic Inclinometer



Datasheet

WinCTi-Tilt software

WinCTi-Tilt is a graphical user interface (GUI) software provided by CTi Sensor Inc. for visualization aide, device configuration, and data logging. WinCTi-Tilt is designed to be user-friendly and intuitive to users. The package can be downloaded from the CTi Sensors website.



Serial interface and data format

TILT-50A uses the following ASCII format, very similar to the widely used NMEA 0183 protocol, for data output:

- Inclinometer message (default): \$CSTLT, A_X, A_Y, A_Z, α_X, α_Y, T*CC<CR><LF>
- Sensor data message (optional): \$CSAGD, A_X, A_Y, A_Z, G_X, G_Y, G_Z, T*CC<CR><LF>

Which:

 $\begin{array}{l} A_{X,}A_{Y},A_{Z} \colon X, Y \text{ and } Z \text{ accelerations in millig (three-axis accelerometer data)} \\ G_{X,} G_{Y}, G_{Z} \colon X, Y \text{ and } Z \text{ angular velocities in deg/s (three-axis gyroscope data)} \\ \alpha_{X,} \alpha_{Y} \colon \text{Roll \& Pitch angles in degrees} \\ \mathbb{T} \colon \text{Internal temperature in degree centigrade} \\ \mathbb{CC} \colon \text{Checksum (Two ASCII characters)} \\ < \mathbb{CR} > < \mathbb{LF} > : \text{Carriage return, and line feed characters} \end{array}$

Example:

- \$CSTLT,+0010.2,-0070.6,+0990.9,+000.59,-004.07,+027*73
- \$CSTLT,+0010,-0070,+0991,+000.58,-004.09,+027*6E

Data rate < 10 Data rate ≥ 10

8-bit Checksum

Checksum is calculated by XORing all characters between \$ and * (not including the \$ and the * characters) based on the NMEA standard. It results in two hexadecimal characters, which are sent in ASCII format.



Datasheet

Configuration commands

TILT-50A uses a simple command format which allows user to change the device configuration and request specific information or data. All commands start with a '[' character, and end with a carriage return character. All responses end with a carriage return and newline character. Table I shows the list of the interface commands for TILT-50A series. Letter 'n' after '['character is the unit number which is set to n=1 by default, and can be set by user to any number from 1 to 9.

Table I: Interface commands for TILT-50A series

Command	Comments	Response	Comments
[n <cr></cr>	Ping unit number n	!n <cr><lf></lf></cr>	Acknowledge ping
[N? <cr></cr>	Request unit number	>Unit Number: n	Returns unit number, default: n=1
[n#m <cr></cr>	Change unit number n to (non- zero) unit number m, 1≤ m ≤ 9	>New Unit Number: n	n=old unit number, m=new unit number, default: n=1
[n#FW <cr></cr>	Save unit number into flash memory	>Current Unit Number, n, was written into flash memory as the default Unit Number for this device!	Unit number will be changed permanently, and current unit number will be saved into the flash memory as the default unit number.
[nV <cr></cr>	Firmware Version	>Firmware Version:d.d	Returns firmware version
[nS <cr></cr>	Serial Number	>Device n Serial Number:ddddddd	Returns 7-digit serial number
[nBnnn <cr></cr>	Baud rate setting: nnn= 2:2400, 4:4800, 9:9600, 19:19200, 38:38400, 57:57600, 115:115200, 230:230400, 460:460800, 921:921600 (bps)	>Change to new Baud Rate:dddddd	Selected baud rate should support current data rate. Otherwise, baud rate will not be changed.
[nBFW <cr></cr>	Save baud rate into flash memory	>Current Baud Rate, dddddd, was written into flash memory as the default Baud Rate!	Baud rate will be changed permanently, and current baud rate will be saved into the flash memory.
[nDnn <cr></cr>	Data rate setting: nn= 1, 2, 5, 10, 20, 25, 40, 50,100, 200 and 400 Hz	>New Output Data Rate: nnn	Default data rate is 2 Hz. New data rate will be saved into the flash memory.
[nARn <cr></cr>	Selecting accelerometer measurement range: n=2, 4, 8	> New Accelerometer Range: +/-ng	New accelerometer range will be saved into the flash memory (Default: ±4 g).
[nGRn <cr></cr>	Selecting gyroscope measurement range: n=0,1,2,3 0:2000, 1:1000, 2:500, 3:250 °/s	>New Gyroscope Range: ±nnnn°/s	New gyroscope range will be saved into the flash memory (Default: ±500°/s)
[nZA <cr></cr>	Zero g offset correction for X and Y axes	>Accelerometer Zero Offset Adjusted: X Offset: ddd, Y Offset: ddd	Resolution of the offset registers is 2 mg, with an effective offset adjustment range of -256 mg to +254 mg for each axis.
[nMxy <cr></cr>	Output messages ON/OFF x= I: Inclinometer data S: Sensor data (accelerometer and gyroscope) y=S: single message C: Continuous message X: Message Off	Data message will be sent out once, continuously or will be turned off	Example for inclinometer data: [1MIS: Sends out one data message [1MIC: Continuously sends out data message [1MIX: Stops sending out data message
[nMICFW <cr></cr>	Save output message ON/OFF status into flash memory	>Current ON/OFF message status was written into flash memory as the default status!	Current message ON/OFF status will be saved into flash memory.
[nFDR <cr></cr>	Factory default reset (firmware version 1.43 and higher)	> Reset to factory default!	Resets the selectable parameters (except baud rate) to their default values.


Dual–Axis Dynamic Inclinometer

Three-Axis Accelerometer Three-Axis Gyroscope

TILT – 50A


Datasheet





Horizontal installation position

Measuring range: ±90° (two-dimensional)



Warranty: This product has 18 months limited warranty. For more information, please visit:

www.CTiSensors.com/warranty

This product is fully designed and manufactured in the U.S.A.

CTI Sensor, INC. 30301 Emerald Valley Parkway, Solon, OH 44139 Phone: (440) 264 - 2370 Email: Sales@CTISensors.com

All contents of this document are subject to change without any notice.