

MFD

SERIES

-

-

-

-

LEFT SIDE SWITCH OPTIONS:

L0 NO BUTTONS  
 L1 SINGLE BUTTON/LEVER  
 L3 3 BUTTON

\*COLOR OPTIONS:

GY ALL GREY  
 BK ALL BLACK  
 BG BLACK/GREY COMBO.

CONTROLLER OPTION:

POTENTIOMETER JOYSTICK (MR SERIES)

R1 2 AXIS NO BUTTON  
 R2 2 AXIS 1 BUTTON  
 R3 3 AXIS NO BUTTON  
 R4 3 AXIS 1 BUTTON  
 R5 3 AXIS 2 BUTTON

HALL EFFECT JOYSTICK (HE1 SERIES)

H1 2 AXIS NO BUTTON STANDARD  
 H2 2 AXIS 1 BUTTON STANDARD  
 H3 2 AXIS NO BUTTON SKIRT HANDLE  
 H4 2 AXIS 1 BUTTON SKIRT HANDLE  
 H5 3 AXIS NO BUTTON STANDARD Z  
 H6 3 AXIS 1 BUTTON STANDARD Z  
 H7 3 AXIS 2 BUTTON STANDARD Z  
 H8 3 AXIS NO BUTTON LOW PROFILE Z  
 H9 3 AXIS 1 BUTTON LOW PROFILE Z  
 H10 3 AXIS 2 BUTTON LOW PROFILE Z

HALL EFFECT CONTROL KNOB (HCK SERIES)

Z1 SINGLE AXIS KNOB

RIGHT SIDE SWITCH OPTIONS:

R0 NO BUTTONS  
 R1 SINGLE BUTTON/LEVER  
 R3 3 BUTTON

\* CABLE ALWAYS SUPPLIED IN GREY COLOR

BK: All components Black Color

GY: All components Grey Color

BG: Grey Housing; Black Joystick, Palm Rest, Buttons