



## BCK16-6-4-A

Ruland BCK16-6-4-A, 3/8" x 1/4" Bellows Coupling, Aluminum, Clamp Style  
With Keyway, 1.000" OD, 1.345" Length




### Description

Ruland BCK16-6-4-A is a clamp bellows coupling with 0.3750" x 0.2500" bores, 1.000" OD, 1.345" length and 3/32" keyway on the 3/8" bore and no keyway on the 1/4" bore. It is zero-backlash and has a balanced design for reduced vibration at high speeds. BCK16-6-4-A is comprised of two anodized aluminum hubs and a stainless steel bellows. The bellows are able to flex while remaining rigid under torsional loads allowing for all types of misalignment to be accommodated. This bellows coupling is lightweight and has low inertia making it suitable for applications with speeds up to 10,000 RPM. Hardware is metric and tests beyond DIN 912 12.9 standards for maximum torque capabilities. Ruland BCK16-6-4-A has four convolutions allowing for high torsional rigidity and making it an excellent fit for precise positioning stepper servo applications as well as encoders. It is machined from solid bar stock that is sourced exclusively from North American mills and RoHS3 and REACH compliant. BCK16-6-4-A is carefully manufactured in our Marlborough, MA factory under strict controls using proprietary processes.

### Product Specifications

<b>Bore (B1)</b>	0.3750 in	<b>Small Bore (B2)</b>	0.2500 in
<b>Keyway (K1)</b>	3/32 in	<b>Keyway (K2)</b>	NK
<b>B1 Max Shaft Penetration</b>	0.626 in	<b>B2 Max Shaft Penetration</b>	0.626 in
<b>Outer Diameter (OD)</b>	1.000 in	<b>Bore Tolerance</b>	+0.001 in / -0.000 in
<b>Length (L)</b>	1.345 in	<b>Length Tolerance</b>	+/- 0.030 in
<b>Hub Width (LH)</b>	0.467 in	<b>Recommended Shaft Tolerance</b>	+0.0000 in / -0.0005 in
<b>Forged Clamp Screw</b>	M3	<b>Screw Material</b>	Alloy Steel
<b>Hex Wrench Size</b>	2.5 mm	<b>Screw Finish</b>	Black Oxide
<b>Seating Torque</b>	2.1 Nm	<b>Number of Screws</b>	2 ea
<b>Dynamic Torque Reversing</b>	15 lb-in	<b>Angular Misalignment</b>	1.5°
<b>Dynamic Torque Non-Reversing</b>	30 lb-in	<b>Parallel Misalignment</b>	0.004 in
<b>Static Torque</b>	60 lb-in	<b>Axial Motion</b>	0.012 in
<b>Torsional Stiffness</b>	244 lb-in/Deg	<b>Moment of Inertia</b>	0.0069 lb-in <sup>2</sup>
<b>Maximum Speed</b>	10,000 RPM	<b>Full Bearing Support Required?</b>	Yes
<b>Zero-Backlash?</b>	Yes	<b>Balanced Design</b>	Yes
<b>Torque Wrench</b>	<a href="#">TW:BT-1R-1/4-18.3</a>	<b>Recommended Hex Key</b>	<a href="#">Metric Hex Keys</a>
<b>Material Specification</b>	Hubs: 2024-T351 Aluminum Bar Bellows: Type 321 Stainless Steel	<b>Temperature</b>	-40°F to 200°F (-40°C to 93°C)
<b>Finish Specification</b>	Sulfuric Anodized MIL-A-8625 Type II, Class 2 and ASTM B580 Type B Black Anodize	<b>Bellows Attachment Method</b>	Epoxy
<b>Manufacturer</b>	Ruland Manufacturing	<b>Country of Origin</b>	USA
<b>Weight (lbs)</b>	0.072900	<b>UPC</b>	634529164341
<b>Tariff Code</b>	8483.60.8000	<b>UNSPC</b>	31163018
<b>Note 1</b>	Stainless steel hubs are available upon request.		
<b>Note 2</b>	Torque ratings are at maximum misalignment.		
<b>Note 3</b>	Performance ratings are for guidance only. The user must determine suitability for a particular application.		
<b>Note 4</b>	Torque ratings for the couplings are based on the physical limitations/failure point of the metal bellows. Under normal/typical conditions the hubs are capable of holding up to the rated torque of the metal bellows. Please consult technical support for more assistance.		

**Prop 65**  **WARNING** This product can expose you to chemicals including Ethylene Thiourea and Nickel (metallic), known to the State of California to cause cancer, and Bisphenol A and Ethylene Thiourea, known to the State

## Installation Instructions

1. Align the bores of the BCK16-6-4-A bellows coupling on the shafts that are to be joined and determine if the misalignment parameters are within the limits of the coupling. (*Angular Misalignment: 1.5°, Parallel Misalignment: 0.004 in, Axial Motion: 0.012 in*)
  2. Fully tighten the M3 screw on the first hub to the recommended seating torque of 2.1 Nm using a 2.5 mm hex torque wrench.
  3. Before tightening the screw on the second hub, rotate the coupling by hand to allow it to reach its free length.
  4. Tighten the screw on the second hub to the recommended seating torque. Make sure the coupling remains axially relaxed and the misalignment angle remains centered along the length of the coupling.
  5. The shafts may extend into the relieved portion of the bore as long as it does not exceed the shaft penetration length of 0.626 in.
-