Data sheet | Item number: 210-840

Push-button marker; for frames, to be snapped in or glued in place; 27 x 27 mm; silver-colored

www.wago.com/210-840

Color: ▭

Data
Technical data

Suitable	for Siemens push-button frame
Marking method	Thermal transfer
Marking	plain
Delivery form	Roll
Delivery form configuration	250 markers/reel; 1 line
Printing device	Smart Printer (Thermal Transfer Printer)

Physical data

Height	27 mm
Width	27 mm
Depth	0.65 mm
Marking surface	27 x 27 mm

Subject to changes. Please also observe the further product documentation!

Do you have any questions about our products?
We are always happy to take your call at +49 (571) 887-44222.

Mechanical Data

Mounting type	Snap-in or adhesive mounting
Smear resistance	in conjunction with 258-5005 Ink Ribbon

Material Data

Color	silver-colored
Material	Polyester
UV resistance	EN 60068-2-5:2010 Procedure B
Adhesive information	Acrylic; permanent; foamed
Halogen-free	Yes
Weight	120 g

Environmental requirements

Ambient temperature (storage)	≥+22 °C
Relative humidity	40 … 50 %

Commercial data

ETIM 8.0	EC001288
ETIM 7.0	EC001288
PU (SPU)	1 pcs
Packaging type	bag
Country of origin	DK
GTIN	4055143965262
Customs tariff number	39191080888

Environmental Product Compliance

RoHS Compliance Status	Compliant,No Exemption

Required accessories

Cover

Cover

Item no.: 210-841
Cover; for frames, snap-in type, 27 x 27 mm; halogen-free; transparent

www.wago.com/210-841

Subject to changes. Please also observe the further product documentation!

WAGO GmbH & Co. KG
Hansastr. 27
32423 Minden
Phone: +49571 887-0 | Fax: +49571 887-169
Email: info.de@wago.com | Web: www.wago.com

Do you have any questions about our products?
We are always happy to take your call at +49 (571) 887-44222.

Downloads
Documentation

Operating Instructions

210-852 Information on handling print material	1 2020 Aug 28	pdf 1.0 MB	Download

Environmental Product Compliance

### Compliance Search

|		
Environmental Product Compliance 210-840 Push-button marker; for frames, to be snapped in or glued in place; 27 x 27 mm; silver-colored	URL	Download

Installation Notes

Stick on frame

Remove the push-button label from the carrier film.

Stick the push-button label onto the push-button frame.


WAGO's push-button label is attached to the push-button frame. A cover cannot be applied.

Subject to changes. Please also observe the further product documentation!

WAGO GmbH & Co. KG
Hansastr. 27
32423 Minden
Phone: +49571 887-0 | Fax: +49571 887-169
Email: info.de@wago.com | Web: www.wago.com

Do you have any questions about our products?
We are always happy to take your call at +49 (571) 887-44222.

Snap into frame

Remove the push-button label from the carrier film. Press and hold the pre-punched carrier film to do this.

Snap the push-button label, with the carrier film on the back, on to the push-button frame. Only the area of the push-button label outside the remaining carrier film is adhesive.

Optional: A cover may also be installed on a push-button frame equipped with latches.

Push-button label and cover are snapped on to the push-button frame.

Subject to changes. Please also observe the further product documentation!

Do you have any questions about our products?
We are always happy to take your call at +49 (571) 887-44222.