



Quick Links

[Food Service Website](#)
[Safety Data Sheets \(SDS\)](#)

Some of these links lead to web-based resources that are not product-specific.

Product Description

The Scotch-Brite™ Scotch-Brick™ Griddle Scrubber 9537, 9537CC is an easy-to-use, one-piece griddle scrubber. It has a built-in heat resistant handle, bonded to an aggressive scouring pad made from synthetic fibers, minerals, and resin. It is designed to be used for cleaning flat top griddles.

Special Features

- Tough, non-rusting and resilient high-quality synthetic fibers to provide long lasting usage
- Abrasive minerals selected to provide superior scouring for griddle cleaning
- Abrasive mineral particles evenly distributed throughout the pad to ensure effective, consistent, and long-lasting performance throughout the life of the pad
- High quality bonding resin system designed to provide resistance to degradation from exposure to hot water, detergents and normal cleaning liquids
- A combination of pad and handle to function as a tool to help keep hands away from hot and dirty surfaces
- Aggressive, heavy duty and open pad construction to provide fast cleaning and multiple uses, resist clogging, and rinse clean easily
- Heat resistant pad and handle to allow for cleaning griddle at operating temperature throughout the day
- Durable handle to resist breakage and provide multiple uses.

Applications

Always test in an inconspicuous area of the surface to be cleaned prior to first use.

Use for cleaning and scouring griddles, replacement for grill bricks and/or other heavy duty scouring where a handled product is desired.

General Use Directions

The scrubber can be used wet or dry on griddle at operating temperature up to 450°F.

1. Hold scrubber by the handle with one hand.
2. Place the pad side against griddle surface, apply pressure evenly and scrub griddle surface in circular motion.

3. Rinse off scrubbed areas with clean water or wipe off with clean, damp cloth. For the griddle, wipe off griddle surface thoroughly with clean, damp cloth.
4. Clean scrubber after each use.

Scrubber Cleaning Instructions

Proper cleaning of the scrubber provides multiple uses and will help extend its life. Used and/or worn-out scrubber can be disposed of in regular kitchen trash.

Scrubbers can be rinsed with warm or hot water or soaked in a cleaning solution to dissolve caked-on soil and grease.

Scrubber Cleaning by Hand

1. Spray or rinse excess food debris from scrubber using a dish sprayer or sink faucet.
2. Wash the scrubber in soapy water to remove any remaining food debris and grease. Remove embedded food debris from the scrubber by hand.
3. Rinse the scrubber with clean water. Make sure no food debris is left on the scrubber. Shake excess water from scrubber and allow to air dry.

If desired, soak scrubber in sanitizer solution. After soaking, shake excess solution from the scrubber, rinse and allow to air dry.

Scrubber Cleaning by Dishwasher

1. Spray or rinse excess food debris from scrubber using a dish sprayer or sink faucet.
2. Place the scrubber in dishwasher and make sure the pad side is exposed to washing.
3. After washing, take scrubber out of dishwasher and allow to air dry.

Product Specifications

Pad Length	6.0 inches
Pad Width	6.0 inches
Color	Pad (Brown); Handle (Red)

Precautionary Summary

IMPORTANT NOTE

Do not use on polished or easily scratched surfaces

Health and Safety

CAUTION

When handling any chemical products, read the manufacturers' container labels and the Safety Data Sheets (SDS) for important health, safety and environmental information. To obtain SDS sheets for 3M products go to [3M.com/SDS](https://www.3m.com/SDS), or by mail or in case of an emergency, call 1-888-364-3577 or 1-651-737-6501.

When using any equipment, always follow the manufacturers' instructions for safe operation.

Technical Information

Technical information and data, recommendations, and other statements provided by 3M are based on information, tests, or experience which 3M believes to be reliable, but the accuracy or completeness of such information is not guaranteed. Such technical information and data are intended for persons with knowledge and technical skills sufficient to assess and apply their own informed judgment to the information. The typical values shown should not be used for the purpose of specification limits. If you have questions about this Product, contact the **Customer Service Department at 1-800-698-4595**.

Product Use

Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty

3M warrants that each 3M product will be free from defects in material and manufacture for 90 days from the date of purchase from 3M's authorized distributor. 3M MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Limited Remedy

If a 3M product does not conform to this warranty, the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

No Extension of Warranty

In the case of an approved warranty claim, the replacement Product will carry only the remaining term of the original warranty period.

Limitation of Liability

Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.