



68HC16MOD-16WIDE

Component List

68HC16MOD-16WIDE

| DESIGNATION | QTY | DESCRIPTION |
|-----------------|-----|--|
| C1 | 1 | 10 μ F, 25V electrolytic capacitor |
| C2, C8-C12, C14 | 7 | 0.1 μ F ceramic capacitors |
| C3 | 1 | 1 μ F ceramic capacitor |
| C4, C5 | 2 | 22 μ F, 25V electrolytic capacitors |
| C6, C7 | 2 | 22pF ceramic capacitors |
| C13 | 1 | 100 μ F, 25V electrolytic capacitor |
| D1 | 1 | 1N4001 diode |
| D2 | 1 | 1N4742A 12V, 1W zener diode |
| J2 | 1 | 2-circuit terminal block |
| J3 | 1 | Right-angle printed circuit board mount, DB9 female socket |
| LED1 | 1 | Light-emitting diode |
| P1, P2 | 2 | 40-pin right-angle male connectors |
| R1 | 1 | 10M Ω , 5% resistor |
| R2 | 1 | 330k Ω , 5% resistor |
| R3, R4 | 2 | 10k Ω , 5% resistors |
| R5 | 1 | 470 Ω , 5% resistor |
| R6 | 1 | 10k Ω , SIP resistor |
| R7 | 1 | 100 Ω , 5% resistor |

| DESIGNATION | QTY | DESCRIPTION |
|-------------|-----|---|
| SW1 | 1 | Slide switch |
| SW2 | 1 | Momentary pushbutton switch |
| U1 | 1 | 68HC16 microcontroller MC68HC16Z1CFC16 (132-pin plastic quad flat pack) |
| U2 | 1 | Maxim MAX233CPP |
| U3 | 1 | 27C256 EPROM containing monitor program |
| U3 | 1 | 28-pin socket |
| U4 | 1 | 7805 regulator, TO-220 size |
| U4 | 1 | Heatsink, thermalloy # 6078 |
| U5, U8 | 2 | 62256 (32K x 8) static RAMs |
| U6, U9 | 2 | 74HCT245 bidirectional buffers |
| U6, U9 | 2 | 20-pin sockets |
| U7 | 1 | Maxim MAX707CPA |
| U10 | 1 | Maxim ICL7662CPA |
| Y1 | 1 | 32.768kHz watch crystal |
| None | 4 | Rubber feet |
| None | 1 | 5" x 5" printed circuit board |

General Description

The 68HC16MOD-16WIDE module is an assembled and tested printed-circuit board intended for use with Maxim's high-speed evaluation kits (EV kits). The module uses a full 16-bit implementation of Motorola's MC68HC16Z1 microcontroller (μ C). It requires an IBM-compatible personal computer and an external DC power supply, typically 12V or as specified in the EV kit manual.

Maxim's 68HC16MOD-16WIDE module allows customers to evaluate selected Maxim products. It is not intended to be used as a microprocessor development platform, and such use is not supported by Maxim.

Detailed Description

Power Input Connector J2

The 68HC16MOD-16WIDE module draws its power from a user-supplied power source connected to terminal block J2. Be sure to note the positive and negative markings on the board. A three-terminal 5V regulator allows input voltages between 8V and an absolute maximum of 20V. The 68HC16MOD-16WIDE module typically requires 200mA of input current.

68HC16 Microcontroller

U1 is Motorola's 68HC16Z1 μ C. Contact Motorola for μ C information, development, and support. Maxim EV kits may use the 16-bit wide bus or use the high-speed queued serial peripheral interface (QSPI™) and the internal chip-select generation.

A MAX707 on the module (U7) monitors the 5V logic supply, generates the power-on reset, and produces a reset pulse whenever the reset button is pressed.

QSPI is a trademark of Motorola Corp.



68HC16MOD-16WIDE

The 68HC16MOD-16WIDE module uses a phase-locked loop (PLL) to set its bus speed. Crystal Y1 is a 32.768kHz frequency reference. The internal oscillator runs 256 times faster than the external crystal. When the 68HC16MOD-16WIDE module is reset, it waits for the PLL to lock before it executes any software. After the PLL locks onto the reference frequency, the software doubles the clock speed by writing to the clock synthesizer control register, selecting a bus speed of 16.78MHz.

U5 and U8, the user RAM area, are 32kbyte CMOS static RAMs.

The 74HCT245 octal buffers let the 68HC16MOD-16WIDE module access a 16-bit port on the interface connectors. This memory-mapped port consists of separate read and write strobes, four chip selects, four address LSBs, and sixteen data bits.

Serial Communications

J3 is an RS-232 serial port, designed to be compatible with the IBM PC 9-pin serial port. Use a straight-through DB9 male-to-female cable to connect J3 to this port. If the only available serial port has a 25-pin connector, you may use a standard 25-pin to 9-pin adapter. Table 1 shows the pinout of J3.

The MAX233 is an RS-232 interface voltage level-shifter with two transmitters and two receivers. It includes a built-in charge pump with internal capacitors that generates the output voltages necessary to drive RS-232 lines.

40-Pin Connectors P1 and P2

The 20 x 2 pin headers (P1 and P2) connect the 68HC16MOD-16WIDE module to a Maxim EV kit. Table 2 lists the function of each pin.

Address Ranges

The 68HC16 μ C generates various enable signals for different address ranges. The ROM and RAM enable signals are fed directly to the respective chips. Several additional signals (P1-33 to P1-36) are available on the data connector to be used by Maxim EV kits. Table 3 outlines the address ranges for each of the elements found on the 68HC16MOD-16WIDE module, and Table 4 is a truth table that describes the logic for each of the module's chip-select outputs. Because the addresses are not completely decoded, the boot ROM and has a shadow at address 08000 hex.

Table 1. Serial Communications Port J3

| PIN | NAME | FUNCTION |
|-----|------|--|
| 1 | DCD | Handshake; hard-wired to DTR and DSR |
| 2 | RXD | RS-232-compatible data output from 68HC16MOD-16WIDE module |
| 3 | TXD | RS-232-compatible data input to 68HC16MOD-16WIDE module |
| 4 | DTR | Handshake; hard-wired to DCD and DSR |
| 5 | GND | Signal ground connection |
| 6 | DSR | Handshake; hard-wired to DCD and DTR |
| 7 | RTS | Handshake; hard-wired to CTS |
| 8 | CTS | Handshake; hard-wired to RTS |
| 9 | None | Unused |

Boot ROM

The boot ROM, U3, is configured as an 8-bit memory device. Resistor R4 pulls data bit 0 low during system reset, forcing the μ C to fetch instructions using only the upper eight data bits. The boot ROM checks the system and waits for commands from the host. Refer to the EV kit manual for specific start-up procedures.

Software

All software is supplied on a disk with the EV kit. Instructions for operating the software are included in the EV kit manual. Refer to the EV kit manual for more information.

Use the 68HC16MOD-16WIDE module only with those EV kits that are designed to support it, and only download code that is targeted for the 68HC16MOD-16WIDE module. Downloading incorrect object code into the 68HC16MOD-16WIDE module will have unpredictable results.

68HC16MOD-16WIDE

68HC16MOD-16WIDE

Self Check

The 68HC16MOD-16WIDE module includes a self-diagnostic routine, which checks the power supply, microprocessor, RAM, and ROM, independent of the EV kit or computer. Note that it does not exercise the RS-232 port or the EV kit 80-pin interface. Connect the power supply to the power terminals (J2) and slide the power switch SW1 to the "ON" position. The LED will light up, and will flash within 5 seconds.

If the LED flashes with a 50% duty cycle, then the module passed its self check.

If the LED flashes with a 10%-on/90%-off duty cycle, then the module failed its self check. Most likely, one of the RAM chips (U5 or U8) is bad.

If the LED remains on and does not flash, then the problem is either U3 (the EPROM), U1 (the microprocessor), U4 (the regulator), the MAX707 reset generator, or the power supply. Use a voltmeter to verify that the power supplies are good; check the power-supply input and the +5V output from the regulator. Use an oscilloscope to see if the 32.768kHz reference oscillator is running.

Table 2. P1 and P2 Data-Connector Signals

| HEADER | PIN | NAME | 68HC16-16WIDE MODULE FUNCTION |
|--------|-------|---|---|
| P1 | 1, 4 | GND | Ground return |
| | 5, 6 | VPREREG | +12V from wall cube |
| | 7, 8 | +5V | +5V from 78M05 |
| | 9, 10 | -12V | -12V from ICL7662 (typically -8V at 15mA load) |
| | 11 | PCS2 | QSPI peripheral chip select 2 |
| | 12 | PCS3 | QSPI peripheral chip select 3 |
| | 13 | PCS0/SS | QSPI peripheral chip select 0 |
| | 14 | PCS1 | QSPI peripheral chip select 1 |
| | 15 | MOSI | QSPI Master Output, Slave Input |
| | 16 | SCK | QSPI Serial Clock |
| | 17 | — | Not used |
| | 18 | MISO | QSPI Master Input, Slave Output |
| | 19 | IC2 | General purpose I/O; Input Capture 2; can be used as an IRQ |
| | 20 | IC1 | General purpose I/O; Input Capture 1; can be used as an IRQ |
| | 21 | OC1 | General purpose I/O; Output Compare 1 |
| | 22 | IC3 | General purpose I/O; Input Capture 3; can be used as an IRQ |
| | 23 | — | Not used |
| | 24 | OC2 | General purpose I/O; Output Compare 2 |
| | 25 | OC4 | General purpose I/O; Output Compare 4 |
| | 26 | OC3 | General purpose I/O; Output Compare 3 |
| 27 | PAI | Pulse Accumulator Input | |
| 28 | IC4 | General purpose I/O; Input Capture 4; can be used as an IRQ | |
| 29 | PWMB | Pulse-Width Modulator B output (drives the status LED) | |
| 30 | PWMA | Pulse-Width Modulator A output | |

68HC16MOD-16WIDE

68HC16MOD-16WIDE

Table 2. P1 and P2 Data-Connector Signals (continued)

| HEADER | PIN | NAME | 68HC16-16WIDE MODULE FUNCTION |
|--------|--------|------------|---|
| P1 | 31 | — | Not used |
| | 32 | PCLK | Pulse Accumulator Clock Input |
| | 33 | CS10/7F800 | Chip select strobe for I/O area \$7F800 |
| | 34 | CS9/7F000 | Chip select strobe for I/O area \$7F000 |
| | 35 | CS7/7E000 | Chip select strobe for I/O area \$7E000 |
| | 36 | CS8/7E800 | Chip select strobe for I/O area \$7E800 |
| | 37 | CS5/WRIO | Active low write strobe for I/O area |
| | 38 | CS1/RDIO | Active low read strobe for I/O area |
| | 39, 40 | — | Not used |
| P2 | 1 | EXTD0 | External I/O data bus LSB |
| | 2–15 | EXTD1–14 | External I/O data bus |
| | 16 | EXTD15 | External I/O data bus MSB |
| | 17, 18 | — | Not used |
| | 19 | A01 | Word address LSB |
| | 20 | A02 | Word address |
| | 21 | A03 | Word address |
| | 22 | A04 | Word address |
| | 23–40 | — | Not used |

Table 3. Memory Map (all address values are in 20-bit hex)

| PIN | FUNCTION |
|-------------|--|
| 00000–07FFF | Boot ROM (U3, strobed by CSBOOT) |
| 08000–0FFFF | Shadow of boot ROM |
| 10000–1FFFF | User RAM (U5 and U8, strobed by CS0 and CS2) |
| 20000–203FF | Internal standby RAM; 1kbyte |
| 20400–7DFFF | Unused |
| 7E000–7E7FF | External chip select (P1 pin 35) (CS7) |
| 7E800–7EFFF | External chip select (P1 pin 36) (CS8) |
| 7F000–7F7FF | External chip select (P1 pin 34) (CS9) |
| 7F800–7FFFF | External chip select (P1 pin 33) (CS10) |
| 80000–F7FFF | Not accessed by the 68HC16 |

| PIN | FUNCTION |
|-------------|---|
| F8000–FF6FF | Unused |
| FF700–FF73F | 68HC16's built-in ADC (not used) |
| FF740–FF8FF | Unused |
| FF900–FF93F | General-purpose timer module (GPT) |
| FF940–FF9FF | Unused |
| FFA00–FFA7F | System integration module (SIM) |
| FFA80–FFAFF | Unused |
| FFB00–FFB07 | Internal standby RAM (SRAM) control registers |
| FFB08–FFBFF | Unused |
| FFC00–FFDFF | Queued serial module (QSM) |
| FFE00–FFFFF | Unused |

68HC16MOD-16WIDE

68HC16MOD-16WIDE

Table 4. Chip-Select Outputs Truth Table

| ADDRESS RANGE | CSBOOT | CS0 | CS1 | CS2 | CS5 | CS6 | CS7 | CS8 | CS9 | CS10 |
|---------------|--------|-----|-----|-----|-----|-----|-----|-----|-----|------|
| 0xxxx read | L | H | H | H | H | H | H | H | H | H |
| 1xxxx read | H | H | H | L | H | H | H | H | H | H |
| 1xxxx write | H | L | H | H | H | H | H | H | H | H |
| 7E0xx read | H | H | L | H | H | L | L | H | H | H |
| 7E0xx write | H | H | H | H | L | L | L | H | H | H |
| 7E8xx read | H | H | L | H | H | L | H | L | H | H |
| 7E8xx write | H | H | H | H | L | L | H | L | H | H |
| 7F0xx read | H | H | L | H | H | L | H | H | L | H |
| 7F0xx write | H | H | H | H | L | L | H | H | L | H |
| 7F8xx read | H | H | L | H | H | L | H | H | H | L |
| 7F8xx write | H | H | H | H | L | L | H | H | H | L |




Figure 1. 68HC16MOD-16WIDE Module Schematic

68HC16MOD-16WIDE

68HC16MOD-16WIDE




Figure 1. 68HC16MOD-16WIDE Module Schematic (continued)

68HC16MOD-16WIDE

68HC16MOD-16WIDE




Figure 1. 68HC16MOD-16WIDE Module Schematic (continued)

68HC16MOD-16WIDE

68HC16MOD-16WIDE




Figure 2. 68HC16MOD-16WIDE Module Component Placement Guide

68HC16MOD-16WIDE

68HC16MOD-16WIDE




Figure 3. 68HC16MOD-16WIDE Module PC Board Layout—Component Side

68HC16MOD-16WIDE

68HC16MOD-16WIDE




Figure 4. 68HC16MOD-16WIDE Module PC Board Layout—Solder Side

68HC16MOD-16WIDE

NOTES

68HC16MOD-16WIDE

68HC16MOD-16WIDE

68HC16MOD-16WIDE

NOTES

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.

12 _____ Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600