

# Sure Cross® RS-485 to USB Adapter Cable



## Datasheet

Figure 1. BWA-UCT-900 and MQDMC-401



- Connects a Sure Cross Gateway, a MultiHop Radio, or an RS-485 sensor to a Windows PC USB port
- **BWA-HW-006** supplies power to one Gateway, one MultiHop Radio operating at 250 mW, or one RS-485 sensor
- **BWA-UCT-900** supplies power for one Gateway or one MultiHop Radio operating at 1 Watt
- Supports baud rates of 9600, 19200, and 38400
- Converts USB to RS-485 (2-wire) with a M12 connector
- Supports Windows XP and Vista
- Download the User Configuration Software, MultiHop Configuration Software, or Sensor Configuration Software free from Banner Engineering's Wireless I/O Products website
- Includes cordset **MQDMC-401** for use with the DX80...C models

Do not use **BWA-HW-006** to connect a Performance Gateway or MultiHop Radio operating in 1 Watt mode. Always configure the Performance and MultiHop models to operate in 250 mW mode before connecting them to your computer to avoid damaging your USB port.

To supply power to 1 Watt radios during configuration, use cable **BWA-UCT-900**.

When plugging this cable into your computer for the first time, give the cable 1 to 2 minutes to check your computer for the proper driver, download the driver, then install it. Plug the cable into your Gateway; the cable should supply enough power to the Gateway to configure it.

For additional information, updated documentation, and a list of accessories, refer to Banner Engineering's website, [www.bannerengineering.com](http://www.bannerengineering.com).

## Models

Model	Adapter	Length
<b>BWA-HW-006</b>	RS-485 to USB	1 meter
<b>BWA-UCT-900</b>	RS-485 to USB, with wall plug to power 1 Watt radios during configuration	

Both cordsets include cordset model **MQDMC-401** for use with the DX80...C models.

## 4-pin M12 Female Connection

Connecting power to the communication pins will cause permanent damage.

Table 1: 4-pin M12 female connector wiring

4-pin M12 Female Quick Disconnect	Pin	Wire Color	DX80 Wiring	DX80...C Wiring
	1	Brown	10 V DC to 30 V DC	V+
	2	White	RS-485 Tx +	Tx
	3	Blue	DC common (GND)	V-
	4	Black	RS-485 Rx -	Rx



## Specifications

---

### Input Power

**BWA-HW-006:** 5 V DC from USB port  
**BWA-UCT-900:** 5 V DC from USB port; 100 to 240 V AC from the plug-in wall transformer

### Output Power

**BWA-HW-006:** 10 V DC power output for a single device transmitting at 250 mW or less  
**BWA-UCT-900:** 24 V DC power output for a single device transmitting at 1 Watt

### Operating Parameters

−40 °C to +80 °C (−40 °F to +176 °F)  
 95% maximum relative humidity (non-condensing)

### USB

Connector: USB type A plug  
 Standard: 2.0

### RS-485

2-wire; 9.6k, 19.2k, or 38.4k; 8 data bits; 1 stop bit; no parity  
 Connector: M12 connector compatible with Banner Sure Cross Gateways and data radios

### Banner Compatible Devices

DX80G\*, DR9M, DR2M models  
**M12FTH3Q** Temperature and Humidity Sensor; **M12FT3Q** Temperature Sensor; **GPS50M** GPS Sensor  
**BWA-HW-006** will not power a MultiHop radio in 1 Watt mode. Use **BWA-UCT-900** to supply power to 1 Watt radios. To use **BWA-HW-006** with a MultiHop radio, set the radio to operate at 250 mW.

### Length

1 meter (This cable can be extended up to 30 meters.)

## Banner Engineering Corp. Limited Warranty

---

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

**THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.**

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: [www.bannerengineering.com](http://www.bannerengineering.com).

For patent information, see [www.bannerengineering.com/patents](http://www.bannerengineering.com/patents).



more sensors, more solutions