

CONBNC004 BNC Jack Panel Mount Connector

The CONBNC004 is a BNC jack panel-mount bulkhead connector which includes a washer and hex nut for installation. The CONBNC004 combines superior performance, compact size, and a convenient bayonet-style (push-twist) mating interface to provide a reliable, easy-to-use connector. Additionally, all Linx connectors meet RoHS and REACH lead free standards and are tested to meet requirements for corrosion resistance, vibration, mechanical and thermal shock



Features

- BNC jack (female socket) connection
 - Gold plated brass center contact
 - Gold plated solder cup receptacle
 - Isolated ground enclosure design
- Brass hex nut and washer
- Bayonet-style (push-twist) connection
- Isolated ground

Applications

- Audio/Video
- Broadcasting
- Test Equipment
- Surveillance Systems
- Ethernet
- Industrial, Commercial, Enterprise

Ordering Information

| Part Number | Description | |
|-------------|--|--|
| CONBNC004 | BNC jack (female socket) panel-mount connector | |

Available from Linx Technologies and select distributors and representatives.

CONBNC004 Datasheet

Performance

Table 1 shows the electrical specifications, insertion loss and VSWR values for the CONBNC004 connector at commonly used frequencies.

Table 1. Electrical Specifications

| Band | Sub-1 GHz | 2 GHz |
|--------------------------|---------------|----------------|
| Frequency Range | 0 Hz to 1 GHz | 1 GHz to 2 GHz |
| Insertion Loss (dB max.) | 0.48 | 0.52 |
| VSWR (max.) | 1.3 | 1.3 |
| Impedance | 50 Ω | |

Insertion loss is the loss of signal power (gain) resulting from the insertion of a device in a transmission line (Figure 1). VSWR (Figure 2) describes how efficiently power is transmitted through the connector. A lower VSWR value indicates better performance at a given frequency.




Figure 1. Insertion Loss for CONBNC004 Connector




Figure 2. VSWR for the CONBNC002 Connector



Datasheet CONBNC004

Table 2. Mechanical Specifications

| Parameter | Value | |
|------------------------------|-------------------------------------|--|
| Mounting Type | Panel-Mount, Solder Cup | |
| Fastening Type | Bayonet-style Coupling (Push/Twist) | |
| Interface in Accordance with | MIL-STD-348B | |
| Weight | 6.8 g (0.24 oz) | |

Table 3. Environmental Specifications

| MIL-STD, Method, Test Condition | | | | |
|---------------------------------|---|--|--|--|
| Corrosion (Salt spray) | MIL-STD-202 Method 101 test condition B | | | |
| Thermal Shock | MIL-STD-202 Method 107 test condition C | | | |
| Vibration | MIL-STD-202 Method 204 test condition B | | | |
| Mechanical Shock | MIL-STD-202 Method 213 test condition B | | | |
| Moisture Resistance | MIL-STD-202 Method 106 test condition D | | | |
| Temperature Range | -20 °C to +105 °C | | | |
| Environmental Compliance | RoHS, REACH | | | |

Product Dimensions




Figure 3. Product Dimensions for the CONBNC004 Connector

Table 4. Connector Components

| Parameter | Value | | |
|----------------|----------|--------|--|
| Connector Part | Material | Finish | |
| Connector Body | Brass | Nickel | |
| Center Contact | Brass | Gold | |
| Insulator | ABS | _ | |
| Washer | Brass | Nickel | |
| Hex Nut | Brass | Nickel | |

CONBNC004 Datasheet

Recommended Mounting Dimensions

Figure 4 shows the recommended enclosure mounting dimensions. The maximum enclosure wall thickness should be no greater than 2.4 mm (0.94 in).




Figure 4. Recommended Mounting Dimensions

Packaging Information

The CONBNC004 connector is packaged in plastic bags of 100 pcs, 2500 Pcs per carton. Distribution channels may offer alternative packaging options.



Datasheet CONBNC004

Connector & Adapter Definitions and Useful Formulas

VSWR - Voltage Standing Wave Ratio. VSWR is a unitless ratio that describes how efficiently power is transmitted through the connector. A lower VSWR value indicates better performance at a given frequency. VSWR is easily derived from Return Loss.

$$VSWR = \frac{10^{\left[\frac{Return \ Loss}{20}\right] + 1}}{10^{\left[\frac{Return \ Loss}{20}\right] - 1}}$$

Insertion Loss - The loss of signal power (gain) resulting from the insertion of a device in a transmission line. Insertion loss can be derived from the power transmitted to the load before the insertion of the component P_{τ} and the power transmitted to the load after the insertion of the component P_{R} .

Insertion Loss (dB) =
$$10 \log_{10} \frac{P_T}{P_R}$$



CONBNC004 Datasheet

Website: http://linxtechnologies.com

Linx Offices: 159 Ort Lane, Merlin, OR, US 97532

Phone: +1 (541) 471-6256

E-MAIL: info@linxtechnologies.com

Linx Technologies reserves the right to make changes to the product(s) or information contained herein without notice. No liability is assumed as a result of their use or application. No rights under any patent accompany the sale of any such product(s) or information.

Wireless Made Simple is a registered trademark of Linx Acquisitions LLC. Other product and brand names may be trademarks or registered trademarks of their respective owners.

Copyright © 2022 Linx Technologies

All Rights Reserved





